



Parts List					
Ref	Class	Part	Description	Qty	Footnote
-		71332A 1	POWER STEERING SEE NOTE	1,	
-		71332A 2	POWER STEERING KIT (PORT M	.1	
1		71317A 1	HYDRAULIC PUMP ASSEMBLY,	1,1	
2		38333	CAP, FILLER - HYDRAULIC PL	1,1	
2A		73873	PULLEY, HYDRAULIC PUMP	1,1	
3	32	65929	HOSE, RETURN - VALVE TO OI	1,1	
3A	32	65231	HOSE, RETURN - OIL COOLER	1,1	
4	54	35830	CLAMP, RETURN HOS E TO HY	1,1	
5	32	55116	HOSE, PRESSURE - POWER S	1,1	
6		61990	STA-STRAP, HYDRAULIC HOSE	1,1	
7		57969	CYLINDER, BOOSTER (B-25-58	1,1	
8		26059	CAP, RUBBER - BOOSTER CYLI	1,1	
9	32	57633	TUBE, EXTENDING - POWER S	1,	
10	32	57634	TUBE, RETRACTING - POWER	1,	
9	32	57632	TUBE, EXTENDING - POWER S	.1	
10	32	57631	TUBE, RETRACTING - POWER	.1	
11		52779	VALVE, POWER STEERING (B-	1,1	
11A	22	67305	FITTING, GREASE - POWER ST	1,1	
12	16	55109	STUD, ADAPTOR - POWER STE	1,1	
13	10	37612	SCREW, CLAMPING (1 1/4")	1,1	
14	13	37459	LOCKWASHER, CLAMPING SCF	1,1	
15	23	60773	SLEEVE, ADJUSTING - CABLE C	1,1	
15A	23	60652	SLEEVE, ADJUSTING - CABLE C	1,1	
16		55110	ADAPTOR, CABLE GUIDE TUBE	1,1	
17	13	20897	LOCKWASHER, DUAL ADAPTO	1,1	
18	11	55111	NUT, DUAL ADAPTOR TO POW	1,1	
19	32	55112	TUBE, CABLE GUIDE	1,1	
20	12	37985	WASHER, CABLE GUIDE TUBE	1,1	
21	11	37984	NUT, CABLE GUIDE TUBE	1,1	
22		64414	GUIDE, CABLE GUIDE TUBE	1,1	
23		57286	BRACKET, MOUNTING - TRANS	1,1	
24	10	31832	SCREW, MOUNTING BRACKET	2,2	
25	13	31848	LOCKWASHER, MOUNTING BR	2,2	
26	10	57968	SCREW, ADJUSTING - MOUNTI	1,1	
27	13	37459	LOCKWASHER, ADJUSTING SC	1,1	
28	11	24883	NUT, ADJUSTING SCREW	1,1	
29	12	20959	WASHER, VALVE ADAPTOR ST	1,1	
30	11	28040	NUT, VALVE ADAPTOR STUD	1,1	
31	11	32882	NUT, MOUNTING TUBE	1,1	
32		57971	TUBE, MOUNTING - BOOSTER	1,1	