



| | | | | Parts List | | |
|-----|-------|----------|------------------------|------------|---------|----------|
| Ref | Class | Part | Description | Qty | Comment | Footnote |
| | | 45194A23 | POWER TRIM KIT | 1 | | |
| 42 | 89 | 68258A 4 | STARTER SOLENOID | 1 | | |
| 43 | 13 | 26996 | LOCKWASHER (#10) | 2 | | |
| 44 | 11 | 68219 | NUT (#10) | 2 | | |
| 45 | 13 | 26993 | LOCKWASHER (5/16") | 2 | | |
| 46 | 11 | 68292 | NUT (5/16") | 2 | | |
| 47 | | 46265 | BOOT | 2 | | |
| 48 | | 74407T | BRACKET | 1 | | |
| 49 | 10 | 21140 | SCREW | 2 | | |
| 50 | 13 | 26992 | LOCKWASHER | 2 | | |
| 51 | 10 | 98256 | SCREW | 2 | | |
| 52 | 13 | 26992 | LOCKWASHER | 2 | | |
| 53 | 11 | 21825 | NUT | 2 | | |
| 54 | 11 | 24656 | NUT | 1 | | |
| 55 | | 26901 | BUMPER | 1 | | |
| 56 | | 55642A13 | CONTROL PANEL ASSEMBLY | 1 | | |
| 57 | | 53107 | JUMPER WIRE (PURPLE) | 1 | | |
| 57 | | 48078 | JUMPER WIRE (RED) | 1 | | |
| 58 | | 55642A17 | CONTROL PANEL | 1 | | |
| 59 | 16 | 55422 | STUD | 4 | | |
| 60 | 12 | 24676 | WASHER | 4 | | |
| 61 | 11 | 27164 | NUT | 4 | | |
| 62 | | 55738A 1 | SWITCH | 3 | | |
| 63 | | 55641 | RETAINER | 1 | | |
| 64 | 10 | 62568 | SCREW | 4 | | |
| 65 | 84 | 87394A20 | HARNES (20') | 1 | | |
| 67 | 54 | 46770 | CLAMP | 1 | | |
| 68 | 10 | 29227 | SCREW | 1 | | |
| 69 | 11 | 34388 | NUT | 1 | | |
| 70 | | 92194A14 | CYLINDER ASSEMBLY | 2 | | |
| 71 | 22 | 74036 | GREASE FITTING | 2 | | |
| 72 | 10 | 45265 | SCREW | 4 | | |
| 73 | 25 | 45016 | O-RING | 4 | | |
| 74 | 10 | 71796 | SCREW | 2 | | |
| 75 | 23 | 45280 | SPACER | 2 | | |
| 76 | 23 | 94907A 1 | BUSHING | 2 | | |
| 77 | | 89108A 3 | BRACKET (PORT) | 1 | | |
| 78 | 10 | 71797 | SCREW | 2 | | |
| 79 | 10 | 68298 | BOLT | 4 | | |
| 80 | 12 | 68410 | WASHER | 4 | | |