



15134

Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
-		846860A 1	PUMP ASSEMBLY, Trim	1		
1		846859A 1	PUMP ASSEMBLY, Hydraulic, Tr	1		
2	22	77366	FITTING	2		
3	85	843809	BOOT	2	(Solenoid to Pump Terminals)	
4		846850 1	PLATE, Pump Mounting	1		
5	89	846070	SOLENOID	2		
6	10	73286	SCREW, (.250-20 x .500)	3		
7	10	844417	SCREW, (.375-16 x .875)	4		
8		844407	BRACKET, Pump Mounting	1		
9	10	844430	SCREW, (.250-20 x 3.00)	2		
10		846866	BRACE, Hydraulic Pump	1		
11	11	846869	NUT, (.375-16)	2		
12	10	57807	SCREW, (#10-16 x .750)	2		
13	12	23243	WASHER, (.260 x .562 x .040 Br	4		
14	84	846134A 1	WIRE ASSEMBLY, Jumper	1		
15	85	843809	BOOT	2		
16	11	814101	NUT, (.250-20)	4		
17		846124	STRAP	1		
18	10	845856	SCREW, (.312-18 x .750)	1		
19	11	846127	NUT, (.312-18 Brass)	1		
20	11	846128	NUT, (.312-18 SS)	1		
21	11	846115	NUT, (#8-32)	4		
22	37	847313	DECAL	1		