



15066

Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
		76509A27	POWER TRIM KIT	1		
1		92975A28	PUMP KIT, Trim	1		
2	84	79147A 3	HARNESS ASSEMBLY	1		
3	88	79091	FUSE, 20 Ampere	1		
4	84	95084A 2	CABLE ASSEMBLY	1		
5	54	55098	J CLIP	1		
6		88075	RETAINER	1		
7	84	86322A15	CABLE ASSEMBLY, (5.50 Inches	1	(Black)	
8	10	41508	SCREW, (.250-20 x .500)	4		
9	89	96158	SOLENOID STARTER	2		
10	11	26419	NUT, (#8-32)	4		
11	84	86322A24	CABLE ASSEMBLY, (4.00 Inches	1	(Black)	
12		94275	LINK	1		
13	13	26992	LOCKWASHER, (.250)	4		
14	11	94330	NUT, (.250-20)	4		
15	88	79023A10	FUSE ASSEMBLY, 110 Ampere	1		
16	12	25908	WASHER, (.265 x .812 x .0625)	1		
17	13	26992	LOCKWASHER, (.250)	1		
18	11	21825	NUT, (.250-28)	1		
19	85	96535	BOOT	1		
20	10	48409	SCREW, (#10-16 x .625)	1		
21	84	79139A12	CABLE ASSEMBLY, Red, Battery	1	(Positive)	
22	10	94247	SCREW, (.375-16 x .750)	2		
23	13	35048	LOCKWASHER, (.375)	2		
24		42419A 1	BRACKET ASSEMBLY	1	(Floor Mounted)	
25	10	59784	SCREW, (.250-10 x 1.00)	4		
26	12	29245	WASHER, (.281 x .500 x .060)	4		
27	10	90285	SCREW, (.312-18 x .625)	1		
28	84	79138A 9	CABLE ASSEMBLY, Black, Batte	1	(Negative)	
29	11	68292	NUT, (.312-18)	1		