



Parts List					
Ref	Class	Part	Description	Qty	Footnote
-		36065A 6	FULL POWER TILT (USE WITH M	1,	
-		36065A 8	FULL POWER TILT(USE WITH MI	1,	
-		36065A 8	FULL POWER TILT(USE WITH MI	1,	
-		36065A 7	FULL POWER TILT (USE WITH M	1,	
--		35978A 4	CONTROL PANEL ASSEMBLY	1,1	
36		35978	PANEL, CONTROL	1,1	
37	10	32866	SCREW, CONTROL PANEL TI	2,2	
38	12	33110	WASHER, FIBER - CONTROL	2,2	
39	11	20190	NUT, CONTROL PANEL SCRE	2,2	
40	23	36273	SPACER, IGNITION SWITCH	1,1	
41		30162	SWITCH, IGNITION - CONTRC	1,1	
42		35019	JUMPER WIRE, IGNITION SW	1,1	
43		34959	SWITCH, ROCKER - CONTRO	1,1	
44	10	32989	SCREW, ROCKER SWITCH TI	2,2	
45		37275	BEZEL, IGNITION SWITCH TC	1,1	
46	37	35408	DECAL, CONTROL PANEL - IN	1,1	
47	37	36035	DECAL, CONTROL PANEL - "F	1,1	
48		37251	HARNES, CONTROL	1,1	
49	54	22875	CLAMP, CONTROL HARNESS	3,3	
50		22789	"D" WASHER, CONTROL HARNE	3,3	
51	12	20878	WASHER, CONTROL HARNE	3,3	
52	10	33615	SCREW, WOOD - CONTROL F	3,3	
53	10	20644	SCREW, CONTROL HARNESS	3,3	
54	11	20645	NUT, CONTROL HARNESS CI	3,3	
55	32	36169	HOSE, CONNECTING - HYDRAL	1,1	
56	22	37363	TEE, CONNECTING HOSE TO L	1,1	
57	32	36167	HOSE, LIFT - TEE TO TILT CYLI	2,2	
58	54	22875	CLIP, LIFT HOSES TO TRANSO	5,5	
58	54	23567	CLIP, CONNECTING HOSES TO	3	
59	10	35401	SCREW, LIFT AND CONNECTIN	5,5	
59	10	35401	SCREW, LIFT AND CONNECTIN	3	
60		22789	"D" WASHER, LIFT AND CONN	5,5	
60		22789	"D" WASHER, LIFT AND CONN	3	
61	32	36169	HOSE, CONNECTING - HYDRAL	1	
62	32	36168	HOSE, LIFT - HOSE BLOCK TO	2	
63	23	35977	GROMMET, LIFT HOSE	2,2	
63	23	36175	GROMMET, CONNECTING HOS	1	
64		36142	BLOCK, HOSE - GIMBAL HOUSI	1	
65	22	35268	PLUG, PIPE - HOSE BLOCK	1	
66	10	36137	SCREW, HOSE BLOCK TO GIMI	2	