



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
		46838A 4	POWER TRIM EXTENSION KIT (1)	1		
		46838A 5	POWER TRIM EXTENSION KIT (2)	1		
1	54	46770	CLAMP, EXTENSION WIRING H	1,1		
2	10	29227	SCREW, EXTENSION WIRING H	1,1		
3	11	26768	NUT, EXTENSION WIRING HAF	1,1		
4		79146	RETAINER, CONNECTOR	1,1		
5	89	68258	SOLENOID	1		
6	13	26996	LOCKWASHER, SOLENOID TEF	2		
7	11	20645	NUT, SOLENOID TERMINAL	2		
8	13	26993	LOCKWASHER, SOLENOID TEF	2		
9	11	68292	NUT, SOLENOID TERMINAL	2		
10		74406	BRACKET, SOLENOID	1		
11		26901	BUMPER, RUBBER - SOLENOID	1		
12	10	21625	SCREW, BRACKET ATTACHING	2		
13	11	21825	NUT, BRACKET ATTACHING SC	2		
14	13	26992	LOCKWASHER, BRACKET ATT	2		
15		26551	BRACKET, EXTENSION - SOLE	1		
16	10	62568	SCREW, WIRE TO EXTENSION	1		