



4471

Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
52	91	14308T 1	RACE TOOL, Bearing	1	SN# USA-0T979999/BEL-0P3254	
52	91	14308T02	BEARING RACE TOOL	1	SN# USA-0T980000/BEL-0P3254	
53	91	14309T 1	INSTALLATION TOOL, Bearing	1	SN# USA-0T979999/BEL-0P3254	
53	91	14309T02	INSTALLATION TOOL, Bearing	1	SN# USA-0T980000/BEL-0P3254	
54	91	14310T 1	WEAR SLEEVE INSTALLATION T	1		
55	91	14311A 2	PRE LOAD TOOL, Bearing	1	SN# USA-0T979999/BEL-0P3254	
55	91	14311A04	TOOL, Preload	1	SN# USA-0T980000/BEL-0P3254	
56	91	19660 1	INDICATOR TOOL, Backlash	1		
-	91	78473	INDICATOR TOOL, Backlash (2.31	1		
57	91	31106T	MANDREL, Bearing Driver Cup	1		
58	91	31108T	DRIVER, Oil Seal	1		
59	91	34569A 1	PULLER ASSEMBLY, Slide Hamme	1		
60	91	46086A 1	PULLER JAW ASSEMBLY	1		
61	91	37350T	MANDREL	1		
62	91	817070	DRIVESHAFT HOLDING TOOL	1		
63	91	58222A 1	DIAL INDICATOR TOOL	1		
64	91	85716	PULLER BOLT	1		
65	91	83155	ADAPTER KIT, Dial Indicator	1		
66	91	83165T	PULLER ASSEMBLY	1		
67	91	856875A 1	BEARING INSTALLATION TOOL	1		
68	91	817057A 1	BACKLASH INDICATOR TOOL	1	SN# USA-0T979999/BEL-0P3254	
68	91	817057A02	TOOL, Backlash Indicator	1	SN# USA-0T980000/BEL-0P3254	
69	91	817058A 1	LOWER DRIVESHAFT BEARING I	1		
70	91	877840A 1	DRIVESHAFT HOLDING TOOL	1		