



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		86617A13	STATOR ASSEMBLY	1		
2	10	40001 20	SCREW (25MM)	2		
3	10	40001 5	SCREW (10MM)	1		
3	10	40001 8	SCREW (12MM)	1		
4		98450A 5	TRIGGER ASSEMBLY	1		
5		11100	CLIP	1		
6	339	7452A15	SWITCH BOX	1		
7	10	40019108	SCREW	3		
8	10	48408	SCREW	1		
9	339	7370A13	IGNITION COIL ASSEMBLY	2		
10	10	40112	SCREW	2		
11		88173	TAB WASHER	2		
12	23	88171	BUSHING, COIL	2		
13	11	45076	NUT	4		
14	84	813715A 2	HIGH TENSION LEAD ASSEMBLY	1		
15	85	63709A 1	BOOT ASSEMBLY, SPARK PLUG	2		
16	33	14814568	SPARK PLUG (NGK #BPZ8HS-15)	2		
16	33	19424	SPARK PLUG (NGK#BP8HS-15)	2		
17	54	816311	STA-STRAP	1		
18		86704A 2	STATOR ASSEMBLY	1		
19	10	40001 23	SCREW	3		
20	86	63813	TERMINAL BLOCK	1		
21	10	48409	SCREW	2		
22	10	62568	SCREW	2		