



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
-	1666	8833A13	GEAR HOUSING, COMPLETE (SH)	1		
-	1666	8833A15	GEAR HOUSING, COMPLETE (LO)	1		
-	1666	8833A14	GEAR HOUSING, COMPLETE (SH)	1		
-	1666	8833A16	GEAR HOUSING, COMPLETE (LO)	1		
1	1666	8833A17	GEAR HOUSING BLACK	1		
1	1666	8833A18	GEAR HOUSING GRAY	1		
43	31	41347A	ROLLER BEARING	1		
44	43	821924A	FORWARD GEAR	1		
45	23	41367	BUSHING	1		
46		813139	CAM FOLLOWER	1		
47	52	821930	CLUTCH	1		
48	17	823951	CROSS PIN	1		
49	24	42204	SPRING	1		
50	44	821929	PROPELLER SHAFT	1		
51	43	821926	REVERSE GEAR	1		
52		42144A	BEARING CARRIER	1		
53	25	33145	O-RING	1		2,15
54	23	821927	BUSHING	1		
55	26	99325	OIL SEAL	1		
56	26	821928	OIL SEAL	1		
57	10	13403	SCREW	1		
58	10	13402	SCREW	2		
59	48	42522A12	PROPELLER (9"X9")	1		
59	48	42524A12	PROPELLER (SAILPOWER/SAILA)	1		
60	23	42091	SPACER	1		
61	11	13914	PROPELLER NUT	1		
62		821932	THRUST HUB	1		
63		822559	HI-REVERSE THRUST CUP	1		