



15179

Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1	19	45907	PLUG, Yellow	1		
2		42956A	COVER ASSEMBLY	1		
3		79022	MARKER	1		
4	10	37572	SCREW, (.190-32 x .380)	2		
5	12	72761	WASHER	2		
6	11	42979	NUT, (M16 x 1.5)	1		
7	12	68229	WASHER	1		
8	261	9008A	FLYWHEEL ASSEMBLY	1		
9	398	8778A23	STATOR	1	(Stamped 398-8778A17 Or 398-87	
9	398	9710A11	STATORS	1	(Stamped 398-9710A15 Or 398-97	
10	10	40073	SCREW, (M5 x 25)	4		
11		99021A	TRIGGER ASSEMBLY	1		
12	50	66015	STARTER MOTOR	1		
13		56703	COLLAR	2		
14		57247	STOP	2		
15	84	93388A	CABLE ASSEMBLY, Black	1		
16	10	69035	SCREW AND LOCKWASHER, (.25	1		
17	84	93389A13	WIRE, Black	1		
18	13	26992	LOCKWASHER, (.250)	1		
19	11	64015	NUT, (#8-32)	1		