



**Quicksilver Lubrication/Sealant
 Application Points**

 Loctite 35 (92-59328-1)

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	1598	8974A23	DRIVE SHAFT HOUSING ASSEM	1	(BLACK)	
1	1598	8974A24	DRIVE SHAFT HOUSING ASSEM	1	(GRAY)	
1	1598	8974A25	DRIVE SHAFT HOUSING ASSY.	1	(TRACKER-GRAPHITE GRAY)	
1	1598	8974A26	DRIVE SHAFT HOUSING ASSEM	1	(BLACK - JET)	
1	1598	8974A27	DRIVE SHAFT HOUSING ASSEM	1	(GRAY - JET)	
2	16	90350 1	STUD	1	(LONG)	
2	16	90350 2	STUD	1	(X-LONG)	
3	17	23784	DOWEL PIN	2		
4	16	90350 12	STUD	4	(LONG)	
4	16	90350 3	STUD	4	(X-LONG)	
5	12	856774	WASHER	5		
6	11	13914	NUT	5		
7		12092A 3	SPACER-DRIVE SHAFT HOUSING	1	(BLACK) X-LONG	
7		12092A 4	SPACER-DRIVE SHAFT HOUSING	1	(GRAY) X-LONG	
8	17	43043	DOWEL PIN (W/HOLE)	1	X-LONG	
8	17	43044	DOWEL PIN	1	X-LONG	
9	22	85822A 4	SPEEDOMETER PICK-UP ASSEM	1		
10	22	43335	CONNECTOR (90 DEGREES)	1		
11	22	85822	CONNECTOR (STRAIGHT)	1		
12		44343 1	MOUNT	2		
13	10	42973	BOLT	2		
14	12	30119	WASHER	2		
15	11	43528	NUT	2		
16		88238A10	GROUND WIRE ASSEMBLY	2		
17	10	41508	SCREW	1		
18		93192	CLAMP	2		
19	11	35521	NUT	4		
20	10	40107 25	SCREW (M8 X 25)	4		
21		67077T	COVER	2	(BLACK)	
21		67077F 1	COVER	2	(GRAY)	
21		67077F 2	COVER	2	(TRACKER-GRAPHITE GRAY)	
22	10	88417	SCREW	4		