



14759

Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1	400	898051A04	CRANKSHAFT ASSEMBLY	1		5
2	28	91800	KEY, Woodruff	1		5
3	23	892309T01	BEARING, Thrust, Crankshaft-Low	2/AR	(Green)	5
3	23	892309T02	BEARING, Thrust, Crankshaft-Low	2/AR	(Navy Blue)	5
3	23	892309T03	BEARING, Thrust, Crankshaft-Low	2/AR	(White)	5
3	23	892309T04	BEARING, Thrust, Crankshaft-Low	2/AR	(Orange)	5
4	26	880525	1 SEAL, Top Main Bearing	1		2,5
5	23	897498T01	BEARING, Main, Crankshaft-Upper	8	(Green)	5
5	23	897498T02	BEARING, Main, Crankshaft-Upper	8	(Navy Blue)	5
5	23	897498T03	BEARING, Main, Crankshaft-Upper	8	(White)	5
5	23	897498T04	BEARING, Main, Crankshaft-Upper	8	(Orange)	5
6		897796	CHAIN, Roller Cam Drive	1		5
7	662	881210T02	CONNECTING ROD ASSEMBLY	4		5
8	10	884441	BOLT	8		5
9	23	892005A01	BEARING, Connecting Rod	8	(Blue)	5
9	23	892005A02	BEARING, Connecting Rod	8	(White)	5
9	23	892005A03	BEARING, Connecting Rod	8	(Orange)	5
10	700	898472T01	PISTON ASSEMBLY, (Standard)	4		5
11	39	881180A03	RING SET, Piston (Standard)	4		5
12		NSS	NOT SOLD SEPARATE, Oil Ri	4		5
13		NSS	NOT SOLD SEPARATE, Pistor	4		5
14		NSS	NOT SOLD SEPARATE, Piston F	4		5
15	40	881184	CIRCLIP	8		5
16	200	897522T04	FLYWHEEL ASSEMBLY	1		5
17	10	880515	BOLT, (M20 x 68)	1		5
18	12	880517	WASHER	1		5
19	23	896883	SPACER	1		5
20	53	896882	RING, Retaining	1		5
21	19	885348	CAP	1		5
22	26	897540	SEAL, Oil	1		2,5
23	53	897785	RING, Retaining	1		5
-	27	897534A07	GASKET SET, Powerhead	1		
-	61	897148A09	LONG BLOCK ASSEMBLY, (75/80	1		
-	61	897148A08	LONG BLOCK ASSEMBLY, (115)	1		