



SEE PAGE 2 FOR PROPELLER
 SHAFT AND COMPONENT PARTS

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
-	1623	2460A11	GEAR HOUSING ASSEMBLY, COM	1	A-1623-2460A11 GEAR HOUSING	
1	1623	2460A 4	GEAR HOUSING ASSEMBLY	1		
2	16	30661	STUD, GEAR HOUSING TO D	1		
3	16	29078	STUD, GEAR HOUSING TO D	2		
4	16	29975	STUD, WATER PUMP BASE A	1		
5	16	37435	STUD, WATER PUMP BASE A	2		
6	31	32898	BEARING, ROLLER - DRIVE S	1		
7	45	38459	DRIVE SHAFT (STANDARD)	1		
8	43	31419	GEAR, PINION - DRIVE SHAFT	1		
9	11	30932	NUT, PINION GEAR TO DRIVE :	1		
10	15	30278A 1	SHIM, DRIVE SHAFT BALL BEA	AR		
11	30	20464	BEARING, BALL - DRIVE SHAFT	1		
12	53	30726	RING, RETAINING - BALL BEAR	1		
10	15	30278A 1	SHIM, WATER PUMP BSAE TO	AR		
13	27	32438	GASKET, WATER PUMP BASE	1		
14	25	30224	"O" RING, WATER PUMP BASE	1		
15	46	35976A 1	WATER PUMP BASE ASSEMBL	1	SERIAL 00000000-01852623	
15	46	38931A 1	WATER PUMP BASE ASSEMBL	1	SERIAL 01852624-09999999	
16	26	31489	OIL SEAL, WATER PUMP BAS	1		
17	26	31507	OIL SEAL, WATER PUMP BAS	1		
18	17	35973	DOWEL PIN, WATER PUMP E	2		
19	27	32433	GASKET, LOWER - WATER PUI	1		
20		32435	PLATE, FACE - WATER PUMP E	1		
21	27	32434	GASKET, UPPER - FACE PLATE	1		
22	46	37433A 1	WATER PUMP BODY ASSEMBL	1		
23		30915	INSERT, WATER PUMP BOD	1		
24	26	31507	OIL SEAL, WATER PUMP BOI	1		
25	12	36446	WASHER, NYLON - WATER IN	1		
26	26	36557	SEAL, RUBBER - WATER INLI	1		
27	47	30221	IMPELLER, WATER PUMP	1		
28	17	29967	PIN, IMPELLER DRIVE	1		
29	10	30720	SCREW, WATER PUMP BODY	1		
30		26992	LOCKWASHER, WATER PUMP	3		
31	11	29598	NUT, WATER PUMP BODY FAS	2		
32	13	26993	LOCKWASHER, WATER PUMP	1		
33	11	28770	NUT, WATER PUMP BODY FAS	1		
34	25	30271	RING, RUBBER - CENTRIFUGAI	1		
35	23	29804	SLEEVE, GUIDE - WATER INLE	1		
36	25	30613	"O" RING, UPPER - DRIVE SHA	1		
37		37641	SEAL, EXHAUST TUBE	1		
38		28051	PLATE, SUPPORT - EXHAUST	1		