



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		37408	HANDLE, CHROME - TOP COWL	1		
2	12	20533	WASHER, CHROME HANDLE TO	6		
3	12	21631	WASHER, CHROME HANDLE TO	AR		
4	11	20361	NUT, CHROME HANDLE TO INSID	4		
5		35496	PAD, BUMPER - TOP COWL HAN	1		
6		37434	HANDLE, INSIDE - TOP COWL	1		
7	10	24234	SCREW, HANDLE TO TOPCOWL	2		
8	13	26993	LOCKWASHER, HANDLE TO TOP	2		
9	2114	2455	COWL, TIP	1		
10	37	37953	DECAL, TOP COWL - MANUAL ST	1		
11		37410A 1	TRIM MOULDING ASSEMBLY, TC	1		
12	10	29227	SCREW, BRASS - MOULDING T	2		
13	10	29226	SCREW, DECORATIVE - MOULI	2		
14	13	26995	LOCKWASHER, MOULDING FA	4		
15	11	26419	NUT, MOULDING FASTENING	4		
16		37569	SHIELD, TOP COWL - REAR	1		
17	37	37863	DECAL, TOP COWL SHIELD - "ME	1		
18	10	37370	SCREW, SHIELD TO TOP COWL	3		
19	13	37371	LOCKWASHER, SHIELD SCREW	3		
20	50	37901	ROPE, STARTER (F60R MANUAL	1		
21		37411	BRACKET, COWL LATCH - TOP C	2		
22	10	37560	SCREW, COWL LATCH BRACKET	4		
23	11	37556	NUT, COWL LATCH BRACKET SC	4		
24		37409	FRAME, TOP COWL SUPPORT	1		
25		37639	MOUNT, RUBBER - TOP COWL F	3		
26	11	20361	NUT, RUBBER MOUNT TO TOP C	6		
27		37714	BRACKET, TOP COWL SUPPORT	1		
28		31014	MOUNT, RUBBER - REAR SUPPC	2		
--	12	20346	WASHER, RUBBER MOUNT	2		
29	13	26992	LOCKWASHER, RUBBER MOUNI	2		
30	11	20088	NUT, RUBBER MOUNT TO REAR	2		
31	10	26065	SCREW, REAR SUPPORT BRACK	4		
32	11	29250	NUT, REAR SUPPORT BRACKET	4		
33	10	37558	SCREW, REAR SUPPORT BRACK	2		
34	13	26993	LOCKWASHER, REAR SUPPORT	2		
35		37412	LEVER, CLAMPING - TOP COWL I	2		
36	23	26819	BUSHING, NYLON - CLAMPING LI	2		
37	12	38006	WASHER, CLAMPING LEVER	2		
38	23	31293	BUSHING, RUBBER - CLAMPING	2		
39	53	30428	FASTENER, CLAMPING LEVER	2		
40	17	29077	PIN, ROLL - CLAMPING LEVER	2		