

Parts List							
Ref	Class	Part	Description	Qty	Comment	Footnote	
1	184	1911A 2	COWL FRONT COVER ASSEMBLY	1,1			
2		26183A 5	EMBLEM, FRONT COVER	1,1			
3	10	29226	SCREW, BRACKET TO FRONT	2,2			
4	13	26395	LOCKWASHER, BRACKET FASTENING	2,2			
5	11	26419	NUT, BRACKET FASTENING SCREW	2,2			
6		29345	BUMPER, RUBBER - FRONT COVER	2,2			
7		30769	KNOB, COWL FRONT COVER FASTENING	1,1			
7		32362	KNOB, COWL FRONT COVER FASTENING	1,1			
8	12	30771	WASHER, COVER FASTENING	1,1			
9	12	26825	WASHER, COVER FASTENING	2,2			
10	24	30772	SPRING, TENSION - FASTENING	1,1			
11	17	29077	ROLL PIN, TENSION SPRING TENSION	1,1			
12		31089	STRIP, SOUND ABSORBING	2,2			
13	194	1942A 2	WRAP AROUND COWL ASSEMBLY	1,1			
14		30412	HANDLE, COWL LATCH	3,3			
15	53	21058	"E" RING, COWL LATCH HANDLE	6,6			
16	17	21057	PIN, HINGE - COWL LATCH HANDLE	6,6			
17		30414	SWIVE, COWL LATCH	3,3			
18		30413	HOOK, COWL LATCH FASTENING	3,3			
19		30021	BLANKET, SOUND ABSORBING	1,1			
20	37	32159	DECAL, WRAP AROUND COWL	1,1			
21	37	32158	DECAL, WRAP AROUND COWL	1,1			
22	37	32160	DECAL, WRAP AROUND COWL	1,1			
--	92	25234	GLUE, ADHESIVE - BLANKET FASTENING	1,1			
--	92	27109	ADHESIVE COMPOUND (3 1/2 OZ)	1,1			

