



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
--	1638	4109A 3	GEAR HOUSING ASSEMBLY, CO	1	RIGHT HAND ROTATION-MERC	
--	1638	4108A 3	GEAR HOUSING ASSEMBLY, CO	1	LEFT HAND ROTATION-MERC 1	
--	1638	4109A 4	GEAR HOUSING ASSEMBLY, CO	1	RIGHT HAND ROTATION-MERC	
--	1638	4108A 4	GEAR HOUSING ASSEMBLY, CO	1	LEFT HAND ROTATION-MERC 1	
59	1638	4109A 1	GEAR HOUSING ASSEMBLY (M	1		
59	1638	4108A 1	GEAR HOUSING ASSEMBLY (M	1		
60	22	20025	PLUG, PIPE (1/4-18 THREAD)	1		
62	16	32129	STUD, GEAR HOUSING TO SI	8		
63	16	49082	STUD, GEAR HOUSING TO SF	1		
64	31	48937	ROLLER BEARING, DRIVE SF	3		
65	22	49523	ELBOW, OIL TUBE (45)	1		
66	10	28634	SCREW, VENT AND FILLING	2		
67	12	20260	WASHER, SEALING-VENT AN	2		
68	31	30956	ROLLER BEARING, PROPELL	1		
69	26	55285	OIL SEAL, PROPELLER SHAF	1		
70	12	39701	WASHER, SPLINED-PROPELLE	1		
71	12	39698	WASHER, PLAIN-PROPELLER	1		
72	11	49252	NUT, PROPELLER	1		
73	44	48882	PROPELLER SHAFT	1		
74	23	56802	SPACER, PROPELLER SHAFT	1		
75	15	20929A 1	SHIM ASSEMBLY, PROPELLER	AR		
76	31	38146A 1	ROLLER BEARING ASSEMBLY,	1		
77		57206A 1	ADAPTOR ASSEMBLY, PROPEL	1		
78	31	54043	ROLLER BEARING ADAPTOR	1		
78	31	54043	ROLLER BEARING, ADAPTOR	1		
79	43	48885	GEAR, PROPELLER SHAFT-RE,	1	RIGHT HAND ROTATION	
80	23	57205	SPACER, PROPELLER SHAFT	1	RIGHT HAND ROTATION	
81	43	48890	GEAR, DOUBLE BEVEL-PROPE	1	RIGHT HAND ROTATION	
82	23	48934	SPACER, PROPELLER SHAFT- ϵ	1	RIGHT HAND ROTATION	
83	12	49808	WASHER, PROPELLER SHAFT	1	LEFT HAND ROTATION	
84	23	49809	SPACER, PROPELLER SHAFT- ϵ	1	LEFT HAND ROTATION	
85	43	48890	GEAR, DOUBLE BEVEL-PROPE	1	LEFT HAND ROTATION	
86	23	57205	SPACER, PROPELLER SHAFT-L	1	LEFT HAND ROTATION	
87	43	48949	GEAR, PROPELLER SHAFT	1	LEFT HAND ROTATION	
88	31	38135A 1	ROLLER BEARING ASSEMBLY,	1		
89	12	48933	WASHER, PROPELLER SHAFT	1		
90	11	39694	NUT, PROPELLER SHAFT	1		
91	23	48932	SPACER, BEARING RETAINER	1		
92	11	48931	NUT, BEARING RETAINER	1		
93		48942	ANCHOR STUD, BEARING RET	1		
94	26	20224	"O" RING, ANCHOR STUD	1		