



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	19	45307	PLUB, FLYWHEEL PULLER THRE	1,1		
2	11	22339	NUT, FLYWHEEL	1,1		
3	12	33001	WASHER, FLYWHEEL NUT	1,1		
4	28	45554	KEY, FLYWHEEL DRIVE	1,1		
5	225	2494A 2	FLYWHEEL ASSEMBLY, COMPLE	1,		
5	225	2494A 8	FLYWHEEL ASSEMBLY, COMPLE	1,1		
6	10	32417	SCREW, FLEXIBLE PLATE TO F	8,		
6	10	49006	SCREW, FLEXIBLE PLATE TO F	8,8		
7	10	32417	SCREW, PLATE AND HUB TO F	8,8		
8	17	26618	PIN, DOWEL - PULLEY TO FLY	1,1		
9		29788	FLANGE, FLYWHEEL PULLEY	1,1		
10		30306	PULLEY, FLYWHEEL	1,1		
11		29787	HUB, FLYWHEEL PULLEY	1,1		
12	398	3301	STATOR, ALTERNATOR	1,1	SERIAL 00000000-02682097	
12	398	3587	STATOR, ALTERNATOR	,1	SERIAL 02682098-09999999	
14	10	52720	SCREW, STATOR TO UPPER EN	4,4		
15	54	22875	CLIP, STATOR LEAD FASTEING	2,2		
16	10	26548	SCREW, STATOR LEAD CLIP (#1	2,2		
16	10	31206	SCREW, STATOR LEAD CLIP (7/	2,2		
15	54	26550	CLIP, STATOR WIRING HARNES	1,1		
16	10	37655	SCREW, STATOR LEAD CLIP FAC	1,1		
17		22789	"D" WASHER, CLIP FASTENING	3,3		