



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		27947	SWIVEL, LINKAGE - ECONOMIZE	1,1		
2		25996A 1	SWIVEL AND LINK ROD ASSEMB	1,1		
3	11	25168	NUT, UPPER LINK ROD ADJUSTI	1,1		
4		37931	ROD, LINK - UPPER	1,1		
5		27948	SWIVEL, UPPER LINK ROD TO T	1,1		
6		38702	LEVER, THROTTLE CONTROL	1,	SERIAL 00000000-02409053	
6		48856	LEVER, THROTTLE CONTROL	1,1	SERIAL 02409054-09999999	
7	12	29245	WASHER, THROTTLE CONTROL	1,1		
8	13	25806	WASHER, WAVE - THROTTLE CC	1,1		
9	11	20361	NUT, UPPER LINK ROD SWIVEL	1,1		
10	10	37559	SCREW, THROTTLE LVR TO EXP	1,1		
11	12	29395	WASHER, THROTTLE CONTROL	1,1		
12	23	45818	BUSHING, THROTTLE CONTROL	1,1		
13	11	20509	NUT, THROTTLE CONTROL LEVI	1,1		
14		37587	SWIVEL, LOWER - THROTTLE C	1,1		
15	11	20361	NUT, THROTTLE CABLE TO LOW	1,1		
16	393	2799A11	DISTRIBUTOR ASSEMBLY, COM	1,1		
17		45409	WIRE RETAINER, HIGH TENSION	2,2		
18		45392	BRACKET, FRONT - WIRE RETAI	1,1		
19		45393	BRACKET, REAR - WIRE REATIN	1,1		
20	10	30663	SCREW, FRONT AND REAR BRA	4,4		
21		45391	SPACER, RUBBER - HIGH TENSII	1,1		
22	33	45191	SPARK PLUG (CHAMPION - L19V)	6,6		
23	32	26330	HOSE, VENT - DISTRIBUTOR TO	1,		
24	32	26407	HOSE, VENT - DISTRIBUTOR TO	1,		
23	32	52031	HOSE, VENT - DISTRIBUTOR TO	,1		
24	32	52030	HOSE, VENT - DISTRIBUTOR TO	,1		
25	22	31521	ELBOW, VENT HOSE TO BOTTOI	2,2		
26	332	2983A 5	IGNITION COIL ASSEMBLY, COMI	1,1		
27	10	46368	SCREW, IGNITION COIL CLAMF	1,1		
27	10	46367	SCREW, IGNITION COIL CLAMF	1,1		
28	11	20645	NUT, IGNITION COIL CLAMPINC	1,1		
29	12	37407	WASHER, IGNITION COIL CLAM	1,1		
30	54	22740	CLIP, LEAD WIRE TO IGNITION	1,1		
31		22789	"D" WASHER, IGNITION COIL C	1,1		
32	11	20190	NUT, IGNITION COIL CLAMPING	2,2		
33	10	22486	SCREW, COIL MOUNTING BRAC	1,1		
34	13	26992	LOCKWASHER, COIL MOUNTING	1,1		
35	10	37561	SCREW, COIL MOUNTING BRAC	2		
35	10	37561	SCREW, COIL MOUNTING BRAC	1(2)		*
36	11	46987	NUT, COIL MOUNTING BRACKET	2		*