



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	1531	1636A 2	DRIVE SHAFT HOUSING ASSEM	1,1,1,1		
1	1531	1630A 2	DRIVE SHAFT HOUSING ASSEM	1,1,1,1		
2	19	29568	PLUG, PLASTIC - DRIVE SHAFT	1,1,1,1		
2	17	29452	ROLL PIN, WATER PUMP CAR	1,1,1,1		
3	10	32089	SCREW, DRIVE - WATER PUM	1,1,1,1		
4	16	26324	STUD, DRIVE SHAFT HOUSING	1,1,1,1		
5	16	26776	STUD, DRIVE SHAFT HOUSING	1,1,1,1		
6	11	21528	NUT, DRIVE SHAFT HOUSING TC	3,3,3,3		
7	11	24652	NUT, POWERHEAD TO DRIVE SH	6,6,6,6		
8	32	28136	TUBE, WATER INLET	1,1,1,1		
9	26	26865	SEAL, RUBBER - WATER INLET	2,2,2,2		
10	23	28135	SLEEVE, RUBBER - WATER INLE	1,1,1,1		
11	25	22174	"O" RING, WATER INLET TUBE	1,1,1,1		
12	12	20413	WASHER, WATER INLET TUBE L	1,1,1,1		
13	27	28132	GASKET, POWERHEAD TO DRIV	1,1,1,1		
14		28119	COVER, EXHAUST RELIEF MUFF	1,1,1,1		
15	27	28120	GASEKT, EXHAUST RELIEF MUFF	1,1,1,1		
16	10	31206	SCREW, EXHAUST RELIEF MUFF	15,15,1		
16	10	30009	SCREW, EXHAUST RELIEF MUFF	15,15,1		
17		29833	SOUND SEAL, DRIVE SHAFT HOI	1,1,1,1		
18		28899	RETAINER, SOUND SEAL - AFT	1,1,1,1		
19		28900	RETAINER, SOUND SEAL - FORV	1,1,1,1		
20	54	28901	FASTENER, SOUND SEAL TO HC	8,8,8,8		
21		29082A 1	LEVER, TOP COWL CLAMPING (F	1,1,1,1		
22		29083A 1	LEVER, TOP COWL CLAMPING (S	1,1,1,1		
23	53	30428	FASTENER, CLAMPING LEVER	2,2,2,2		
24	17	29077	ROLL PIN, CLAMPING LEVER (S	2,2,2,2		
25	23	31293	BUSHING, RUBBER CLAMPING L	2,2,2,2		
25	23	25915	BUSHING, RUBBER - CLAMPING	2,2,2,2		
26	23	26819	BUSHING, NYLON - CLAMPING LI	2,2,2,2		
26	12	26825	WASHER, CLAMPING LEVER SH	2,2,2,2		
26	18	20180	COTTER PIN, CLAMPING LEVER	2,2,2,2		
23	53	30428	FASTENER, CLAMPING LEVER H	2,2,2,2		
27		26836	LEVER, TROLL CONTROL	1,1,1,1		
28	23	26841	BUSHING, NYLON - TROLL CONT	2,2,2,2		
29		28112	ARM, TROLL CONTROL LEVER	1,1,1,1		
30	13	25906	WASHER, WAVE - TROLL LEVER	1,1,1,1		
31	10	28249	SCREW, SET - ARM TO TROLL C	2,2,2,2		
32	25	30258	GROMMET, RUBBER - SHORTINI	1,1,1,1		
33	1534	1427	SADDLE	1,1,1,1		
34		28922	RIMMER, RUBBER, SADDLE (UR	1,1,1,1		