



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		23009A	1 FUEL PUMP ASSEMBLY	1,1,1,1		
1		30269A	2 FUEL PUMP ASSEMBLY (SEE NO	1,1,1,1		
2	27	23005	GASKET, CHECK VALVE TO PU	2,2,2,2		
3	21	30430	VALVE, CHECK	2,2,2,2		
4		23004	RETAINER, CHECK VALVE	1,1,1,1		
5	10	20037	SCREW, RETAINER TO HOUSI	2,2,2,2		
6	27	24863	GASKET, FUEL PUMP	2,2,2,2		
7		23014	DIAPHRAGM, FUEL PUMP	1,1,1,1		
8	10	29246	SCREW, FUEL PUMP MOUNTIN	2,2,2,2		
9	10	28712	SCREW, FUEL PUMP MOUNTIN	1,1,1,1		
10	32	28599	FUEL LINE, FUEL PUMP TO CAR	1,1,1,1		
11	22	25443	FITTING, FUEL PUMP OUTLET	1,1,1,1		
11	22	23125	FITTING, FUEL PUMP OUTLET	1,1,1,1		
12	22	23125	FITTING, FUEL PUMP INLET	1,1,1,1		
13	22	22995	FITTING, FUEL PUMP FITTING T	1,1,1,1		
14	22	22946	SLEEVE, RUBBER	1,1,1,1		
15	11	22948	NUT, FITTING	1,1,1,1		
16	32	28474	FUEL LINE, ADAPTOR TO FUEL F	1,1,1,1		
16	32	30301	FUEL LINE, ADAPTOR TO FUEL F	1,1,1,1		
17		30188	CUP WASHER, ADAPTOR	1,1,1,1		
18	24	23067	SPRING, ADAPTOR STEM	1,1,1,1		
19	25	20415	"O" RING, ADAPTOR STEM	1,1,1,1		
20		23069	STEM, CHECK UNIT ADAPTOR	1,1,1,1		
21		22833	ADAPTOR, CHECK UNIT	1,1,1,1		
22	10	21091	SCREW, CHECK UNIT ADAPTOR	2,2,2,2		
23	12	20028	WASHER, ADAPTOR FASTENING	2,2,2,2		
24	11	28941	NUT, ADAPTOR FASTENING SCF	2,2,2,2		