



				Parts List		
Ref	Class	Part	Description	Qty	Comment	Footnote
1	328	1336A 1	FLYWHEEL ASSEMBLY	1,1,1,1		
1	398	1338A 1	STATOR ASSEMBLY, COMPLETE	1,1,1,1		
1	398	1736A 1	STATOR ASSEMBLY, COMPLETE	.1,1,1,1		
2	398	1338	STATOR AND CORE	1,1,1,1		
2	398	1338	STATOR AND CORE	2		
2	398	1736	STATOR AND CORE	.1,1,1,1		
2	398	1736	STATOR AND CORE	2		
3	398	963	SCREW, CORE FASTENING	4,4,4,4		
4	13	21144	LOCKWASHER, CORE FASTEN	4,4,4,4		
5	398	173	COIL, IGNITION	2,2,2,2		
6	10	21130	SCREW, GROUND TERMINAL	2,2,2,2		
7	398	190	COVER, BREAKER COMPARTM	1,1,1,1		
8	10	30429	SCREW, SEALING COVER FAS	4,4,4,4		
9	398	174	BREAKER ASSEMBLY	2,2,2,2		
10	10	23977	SCREW, BREAKER FASTENING	2,2,2,2		
11	12	21135	WASHER, BREAKER FASTENIN	2,2,2,2		
12	13	21134	LOCKWASHER, BREAKER FAS	2,2,2,2		
13	10	23976	SCREW, BRAKER CONNECTIO	2,2,2,2		
14	398	693	CONDENSER	2,2,2,2		
15	10	21136	SCREW, CONDENSER FASTEN	2,2,2,2		
16	13	21134	LOCKWASHER, CONDENSER F	2,2,2,2		
17	398	192	WICK, FELT	1,1,1,1		
18	398	193	PLUG, FELT	1,1,1,1		
19	398	965	LEAD WIRE	2,2,2,2		
20		20623	MARKER, "TOP" - LEAD WIRE	1,1,1,1		
21	32	21137	TUBE, LEAD WIRE (PORT SIDE	1,1,1,1		
22	23	25217	BUSHING, LEAD WIRE (STARB	1,1,1,1		
23	398	182	CLAMP, PLASTIC - LEAD WIRE	3,3,3,3		
24	10	23977	SCREW, LEAD WIRE CLAMP (S	1,1,1,1		
25	10	21139	SCREW, LEAD WIRE CLAMP (L	1,1,1,1		
26	12	21135	WASHER, LEAD WIRE CLAMP	2,2,2,2		
27	13	21134	LOCKWASHER, LEAD WIRE CL	2,2,2,2		
28	398	1098	BUSHING, LEAD WIRES	1,1,1,1		
29		20119	PROTECTOR, SPARK PLUG	2,2,2,2		
30	398	1872	GROUND LEAD, MAGNETO TO	.1,1,1,1		
31	23	30419	SLEEVE, GROUND LEAD INSUL	.1,1,1,1		
32	25	29051	GROMMET, GROUND LEAD TH	.1,1,1,1		
33	33	22805	SPARK PLUG (CHAMPION J7J)	2,2,2,2		
33	33	20127	SPARK PLUG (CHAMPION J6J)	2,2,2,2		
33	33	28915	SPARK PLUG (AC-M44C)	2,2,2,2		
34		28926A 1	THROTTLE CONTROL CAM ASSE	1		