



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		28089	BODY, SYNCHRONIZER	1,1,1,1		
2	23	28247	BUSHING, NYLON - SUPPORT SF	1,1,1,1		
3		28215	SHAFT, SUPPORT - PRIMARY DF	1,1,1,1		
4		28808	SHAFT, INPUT - PRIMARY DRIVE	1,1,1,1		
5		28216	BALL JOINT, NYLON - INPUT SHA	1,1,1,1		
6	17	28235	PIN, BALL JOINT TO INPUT AND	1,1,1,1		
7	23	20571	BUSHING, RUBBER - INPUT SHA	1,1,1,1		
8	23	28478	SLEEVE, INNER - INPUT SHAFT	1,1,1,1		
9	32	28475	TUBE, OUTER - INPUT SHAFT (R	1,1,1,1		
10	24	28234	SPRING, INPUT SHAFT	1,1,1,1		
11		28153	ECCENTRIC, PRIMARY DRIVE SF	1,1,1,1		
12		28213A 1	LINK, PRIMARY TO MAGNETO CI	1,1,1,1		
13		28226A 1	ACTUATOR ASSEMBLY, SHIFT C	1,1,1,1		
14	29	25015	PIN, ROLLER - ECCENTRIC POSI	1,1,1,1		
15	12	28463	WASHER, ACTUATOR FASTENIN	1,1,1,1		
16	23	28462	SPACER, ACTUATOR FASTENIN	1,1,1,1		
17	10	28425	SCREW, ACTUATOR TO PRIMAR	1,1,1,1		
18	10	29197	SCREW, SYNCHRONIZER BODY	2,2,2,2		
19		28111	LEVER, MAGNETO CONTROL	1,1,1,1		
20	23	26841	BUSHING, NYLON - MAGNETO CI	1,1,1,1		
21	23	26856	BUSHING, NYLON - MAGNETO CI	2,2,2,2		
22		28354	CAM, CONTROL LEVER	1,1,1,1		
23		28353	PLATE, CLUTCH - REAR	1,1,1,1		
24	12	20583	WASHER, CONTROL LEVER TO I	1,1,1,1		
25	18	28365	COTTER PIN, LOCK - CONTROL L	1,1,1,1		
26	23	28352	BUSHING, NYLON - SYNCHRONI	1,1,1,1		
27		28355	PLATE, CLUTCH - FRONT	1,1,1,1		
28	30	28685	BALL, DETENT - CLUTCH PLATE	1,1,1,1		
28		28356	PLATE, CLUTCH RETAINING (NO	1,1,1,1		
29	24	28357	SPRING, CLUTCH PLATE TENSIC	2,2,2,2		
30	16	29977	STUD, CLUTCH RETAINING PLA	2,2,2,2		
31	11	20110	NUT, CLUTCH RETAINING PLAT	2,2,2,2		
32		28218A 1	SHIFT CAM ASSEMBLY	1,1,1,1		
33		28221	LEVER, DETENT	2,2,2,2		
34	24	28233	SPRING, TENSION - DETENT LEV	1,1,1,1		
35	23	26841	BUSHING, NYLON - SHIFT CAM S	2,2,2,2		
36	12	20546	WASHER, SHIFT CAM SHAFT	1,1,1,1		
37	18	21071	COTTER PIN, SHIFT CAM SHAFT	1,1,1,1		
38	13	27071	WASHER, WAVE - SHIFT CAM PI	1,1,1,1		
39	18	26953	COTTER PIN, UPPER SHIFT SHA	1,1,1,1		
40		28109	LEVER, CAM CONTROL	1,1,1,1		