



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	25	26802	"O" RING, UPPER DRIVE SHAFT	1,1,1,1		
2	12	20684	SLINGER, CENTRIFUGAL	1,1,1,1		
3		29436	PLATE, TOP - WATER PUMP	1,1,1,1		
4	47	26554	IMPELLER, WATER PUMP	1,1,1,1		
5	46	29445A	1 WATER PUMP CARTRIDGE ASS	1,1,1,1		
6		20811	SLEEVE, WATER PUMP CARTF	1,1,1,1		
7		29435	PLATE, BOTTOM	1,1,1,1		
8	26	20070	OIL SEAL, WATER PUMP CART	1,1,1,1		
9	25	29439	"O" RING, WATER PUMP CART	1,1,1,1		
10		29437A	1 SEAL RETAINER ASSEMBLY	1,1,1,1		
11	26	26782	OIL SEAL, RETAINER	1,1,1,1		
12	25	20812	RING, RUBBER - SEALING	1,1,1,1		
13	12	29687	"L" WASHER, WATER PUMP CAF	1,1,1,1		
14		26783	SLEEVE, DRIVE SHAFT BALL BEA	1,1,1,1		
15	30	21776	BEARING, BALL - UPPER DRIVE	1,1,1,1		
16	15	26728A	1 SHIM, BALL BEARING TO DRIVE	OPT,OI		
17	53	29438	RING, LOCK - WATER PUMP CAF	1,1,1,1		
18	45	29444A	1 DRIVE SHAFT ASSEMBLY(UPPEF	1,1,1,1		
19	23	26660	BUSHING, DRIVE SHAFT	1,1,1,1		
20	28	28784	KEY, DRIVE SHAFT	1,1,1,1		
21	12	27988	WASHER, CLUTCH RETAINING	1,1,1,1		
22	24	27991	SPRING, NEUTRAL	1,1,1,1		
23	12	26835	WASHER, THRUST - NEUTRAL S	1,1,1,1		
24	43	27994A	1 INPUT DRUM AND GEAR ASSEM	1,1,1,1		
25	23	26660	BUSHING, INPUT GEAR AND D	2,2,2,2		
26		27995	SLEEVE, REVERSE CONTROL -T	1,1,1,1		
27	24	27021	SPRING, FORWARD AND REVEF	1,1,1,1		
27		27987A	2 TRUNNION CARRIER ASSEMBLY	1,1,1,1		
28		27987A	1 TRUNNION CARRIER ASSEMBL	1,1,1,1		
29	43	26688	GEAR, IDLER	2,2,2,2		
30	12	29447	WASHER, THRUST - IDLER GE	2,2,2,2		
31		27986	SHAFT, IDLER GEAR TO CARR	2,2,2,2		
32		28000	SHAFT, PILOT - TRUNNION CARI	1,1,1,1		
33	28	28002	KEY, SPRING CLUTCH	1,1,1,1		
34	29	26689	PIN, ROLLER - KEY AND SHAFT	1,1,1,1		
35	12	26661	WASHER, THURST - PILOT SH	1,1,1,1		
36	12	29446	WASHER, THRUST - PILOT SH	1,1,1,1		
37		27992	SLEEVE, TRUNNION CARRIER	1,1,1,1		
38		27072	SHAFT, UPPER SHIFT	1,1,1,1		
39	11	20190	NUT, PUSH LINK TO UPPER SHII	1,1,1,1		
40	11	20645	NUT, ADJUSTING - SLEEVE LOCK	1,1,1,1		