



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
		28702A 2	STEERING HANDLE ASSEMBLY	1,1,1,1		
1		28702A 1	STEERING HANDLE ASSEMBLY	1,1,1,1		
2	24	28101	SPRING, REVERSE SHAFT T	1,1,1,1		
3		28099	SHAFT, REVERSE STOP	1,1,1,1		
4	12	28105	WASHER, REVERSE SHAFT	1,1,1,1		
5		28098	GRIP, RUBBER - STEERING H	1,1,1,1		
6	30	28103	BALL, STEEL - REVERSE SHAF	1,1,1,1		
7	23	28104	BUSHING, NYLON - HANDLE SH	1,1,1,1		
8		28097	TUBE, STEERING HANDLE	1,1,1,1		
9	23	28100	BUSHING, NYLON - HANDLE SH	1,1,1,1		
10	12	20084	WASHER, STEERING HANDLE	1,1,1,1		
11	24	26703	SPRINGER, STEERING HANDLE S	1,1,1,1		
12	14	26706	TAB WASHER, YOKE PIN HOLE	1,1,1,1		
13		30235	YOKE, STEERING HANDLE	1,1,1,1		
14	17	26862	PIN, YOKE TO STEERING HAN	1,1,1,1		
15		29518	ADAPTOR, HANDLE	1,1,1,1		
16	10	21091	SCREW, HANDLE ADAPTOR CLA	2,2,2,2		
17	11	20361	NUT, HANDLE ADAPTOR CLAMP	1,1,1,1		
18	11	20586	NUT, HANDLE ADAPTOR CLAMP	1,1,1,1		
19	12	20533	WASHER, HANDLE ADAPTOR CL	1,1,1,1		
20		28480A 2	CONTROL SHAFT ASSEMBLY	1,1,1,1		
21	10	28663	SCREW, CONTROL SHAFT TO S'	1,1,1,1		
21	10	26774	SCREW, CONTROL SHAFT TO S'	.....,1		
22	15	28485	SHIM, ADAPTOR TO STEERING	2,2,2,2		
23		30205	BRACKET, STEERING ARM	1,1,1,1		
24	10	21259	SCREW, STEERING BRACKET TI	1,1,1,1		
25	10	21807	SCREW, STEERING BRACKET TI	2,2,2,2		
26	11	24652	NUT, REAR BRACKET FASTENIN	2,2,2,2		
27		26711	PIVOT, STEERING HANDLE ADA	2,2,2,2		
28	15	26707	SHIM, ADAPTOR PIVOT TO BRAC	2,2,2,2		
29	10	28592	SCREW, HANDLE PIVOT FASTEN	2,2,2,2		
30		30244	SHORTING SWITCH ASSEMBLY	,1,1,1,1		
31	24	30247A 1	SPRING AND CONTACT ASSEM	,1,1,1,1		
32		23987	COVER, RUBBER - SHORTING	,1,1,1,1		
33		30260	TERMINAL, SHORTING SWITC	,3,3,3		
34	53	30248	RING, RETAINING - SHORTING S	,1,1,1,1		
35	25	30226	GROMMET, RUBBER - SHORTINI	,1,1,1,1		
36	54	24836	CLIP, SHORTING SWITCH LEAD	,1,1,1,1		
37		22789	"O" WASHER, SHORTIN GSWITC	,1,1,1,1		
38	10	31206	SCREW, SHORTING SWITCH LE	,1,1,1,1		
38	10	20099	SCREW, SHORTING SWITCH LE	1		