



11988

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	10	88447	SCREW, (.190-32 x 1.62)	3		
2	12	38833	WASHER	3		
3	23	94304	SPACER	3		
4		13381	PLATE	1		
5		821889A30	REV LIMITER	1		
6	84	823147A 5	HARNNESS, Adaptor - Rev Limiter	1		
7	91	30500A 2	GREASE KIT	1		5
8	46	42579A 3	WATER PUMP BASE ASSEMBLY	1		
9	27	42631 1	GASKET	1		4,10,8
10	26	89238	OIL SEAL	1		8
11	26	16977	OIL SEAL	1		8
12	27	85608 1	GASKET	1		4,10,8
13	27	85609 1	GASKET	1		4,10,8
14		32435	FACE PLATE	1		10
15	46	96148A 1	WATER PUMP BODY ASSEMBLY	1		10
16		48752	INSERT	1		10
17	26	38970	SEAL	1		4,10,8
18	47	89984 1	IMPELLER	1		10
19	28	56654	KEY	1		10
20	10	96411	SCREW, (#14-8 x 2.25)	1		10
21	12	29245	WASHER, (.281 x .500 x .060)	2		
22	11	13438	NUT, (.250-28)	2		
23	10	19924275	SCREW, (.312-18 x 2.75)	1		
24	12	36001	WASHER	1		
25	23	29804	SLEEVE	1		10
-	27	815791A92	ENGINE GASKET SET	1		
-	46	96148A 5	WATER PUMP REPAIR KIT	1		
-	26	89238A 2	SEAL KIT	1		