

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	187	1954	BOTTOM COWL	1,1,1,1		
2	37	31035	DECAL, SHIFT - CHOKE - STOP - I	1,1,1,1		
2	37	35512	DECAL, SHIFT - CHOKE - STOP - I	1,1,1,1		
2A	37	35824	DECAL, SHIFT - BOTTON COWL	1,1,1,1		
3		31408	LEVER, CLAMPING - PORT	1,1,1,1		
4		31409	LEVER, CLAMPING - STARBOARD	1,1,1,1		
5	53	30428	FASTENER, CLAMPING LEVER	2,2,2,2		
6	17	29077	PIN, ROLL - CLAMPING LEVER	2,2,2,2		
7	12	38744	WASHER, CLAMPING LEVER	2,2,2,2		
8	23	26819	BUSHING, NYLON - CLAMPING LI	2,2,2,2		
8	23	26819	BUSHING, NYLON - CLAMPING LI	4		
9	23	31293	BUSHING, RUBBER - CLAMPING LI	2,2,2,2		
10	27	31557	GASKET, POWERHEAD TO BOTI	1,1,1,1		
11	27	30801	GASKET, EXHAUST REFEIF COVI	1,1,1,1		
12		30800	COVER, EXHAUST RELIEF	1,1,1,1		
13	10	31206	SCREW, EXHAUST RELIEF COVE	7,7,7,7		
14	37	37750	DECAL, BOTTOM COWL - PORT	1	PART OF A-37-37745A1 DECAL S	
15	37	37749	DECAL, BOTTOM COWL - STARB	1	PART OF A-37-37745A1 DECAL S	
--		30852A 1	STOP SWITCH ASSEMBLY	1		
--		32372A 2	STOP SWITCH ASSEMBLY	1,1,1,1		
16		30853	HARNESS, STOP SWITCH	1		
16		32372	HARNESS, STOP SWITCH	1,1,1,1		
17	12	30856	WASHER, SEALING - STOP Sw	1,1,1,1		
18		30859	INSULATOR, SLEWVE - INNER	1,1,1,1		
19	24	30858A 1	SPRING AND CONTACT ASSEM	1,1,1,1		
20		30854	COVER, STOP SWITCH	1,1,1,1		
21	13	21972	LOCKWASHER, STOP SWITCH	1,1,1,1		
22	11	21971	NUT, STOP SWITCH CONNECT	1,1,1,1		
23	10	28634	SCREW, BOTTOM COWL FLUSHI	1,1,1,1		
24	12	20260	WASHER, BOTTOM COWL FLUSI	1,1,1,1		

