



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	421	1900	CRANKSHAFT	1,1,...		
1	421	2224	CRANKSHAFT	1,1,1		
2	532	1938A 1	MAIN BEARING ASSEMBLY (VAL)	1,1,1,1		
3	17	20032	PIN, DOWEL-MAIN BEARING	10,10,1		
4	10	37601	SCREW, MAIN BEARING CLAM	2,2,2,2		
5	17	20032	PIN, DOWEL-MAIN BEARING TO	1,1,1,1		
6	34	31942A 1	REED SET, MATCHED-MAIN BEA	1,1,1,1		
7	34	20053	REED STOP, MAIN BEARING REI	4,4,4,4		
8	10	27304	SCREW, REED STOP MOUNTING	4,4,4,4		