



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	421	2224	CRANKSHAFT	1		
2		63991A 1	CARRIER ASSEMBLY, SEAL CRA	1	SERIAL 03482753-09999999	
3		64988	SEAL, CRANKSHAFT CARRIER	1	SERIAL 03482753-09999999	2
4	532	1938A 6	MAIN BEARING ASSEMBLY (VAL)	1		
5	17	20032	PIN, DOWEL - MAIN BEARING	2		
5	17	55453	PIN, DOWEL - REED LOCATING	8		
6	10	56781	SCREW, MAIN BEARING CLAMP	2		
7	17	20032	PIN, DOWEL - MAIN BEARING TC	1		
8	34	31942A 1	REED SET, MATCHED - MAIN BE.	1		
9	34	20053	REED STOP, MAIN BEARING REE	4		
10	10	27304	SCREW, REED STOP MOUNTING	4		