



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	336	4524A 1	COVER ASSEMBLY	1		
2	10	60491	SCREW, COVER TO MODULE (5/	2		
3	336	4516A 2	IGNITION MODULE ASSEMBLY	1		
4	10	59800	SCREW, MODULE TO STATOR (E	2		
5	10	36046	SCREW, MODULE - COIL LEADS	3		
6	13	26996	LOCKWASHER, MODULE - IGNIT	2		
7	11	45076	NUT, MODULE - IGNITION COIL L	2		
8	336	4468A 1	COIL, HIGH SPEED	1		
8	336	4467A 1	COIL, LOW SPEED	1		
9	54	59538	CLIP, COIL RETAINING	2		
10	54	59539	CLIP, COIL RETAINING	2		
11	336	4463	CONDENSER	1		
12	10	62269	SCREW, CONDENSER ATTACHIN	2		
13	336	4477A 1	STATOR ASSEMBLY	1		
14	336	4458	PLATE, STATOR HOLD DOWN	2		
15	10	35400	SCREW, HOLD DOWN PLATE TC	4		
16	15	33910015	SHIM, STATOR PLATE TO UPPE	1		
17	336	3989	WICK, CAM WIPER - STATOR AS	1		
18	336	4318A 3	MAKER ASSEMBLY, STATOR HO	2		
19	10	56266	SCREW, MAKER TO STATOR HO	4		
20		34363A 4	THROTTLE CAM BRACKET ASSE	1		
21	54	34449	CLAMP, THROTTLE CAM BRACK	1		
22	10	53296	SCREW, CAM BRACKET TO STA	2		
23	10	34696	SCREW, THROTTLE CONTROL L	1		
24	12	34392	WASHER, CONTROL LEVER SCF	2		
25	11	28656	NUT, CONTROL LEVER SCREW	1		
26		61641	CAM, THROTTLE	1	SERIAL 00000000-03482752	
26		63839	CAM, THROTTLE	1	SERIAL 03482753-09999999	
27	10	28707	SCREW, THROTTLE CAM TO CAI	2		
28		56319A 6	LEAD ASSEMBLY, STOP SWITCF	1		
29		59060	BOOT, LEAD ASSEMBLY	1		
30		56757A 3	LEAD ASSY, CONDENSER TO BC	1		
31	10	30663	SCREW, STATOR GROUND WIR	1		
32		56318A 6	LEAD ASSEMBLY, MODULE TO I	1		
33		56318A 5	LEAD ASSEMBLY, MODULE TO I	1		
34		38938	BOOT, LEAD ASSEMBLY	2		
35		56316A 3	CABLE ASSEMBLY, STATOR HOL	1		
35		56317A 3	CABLE ASSEMBLY, STATOR HOL	1		
36		38938	BOOT, CABLE	2		
37	336	4460	INSULATOR, CABLE TO CONTAC	2		
38	11	56326	NUT, CABLE INSULATOR	2		