



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	251	6194A 1	FLYWHEEL ASSEMBLY (MANUAL	1		
1	251	6105A 1	FLYWHEEL ASSEMBLY (ELECTR	1		
1	251	6105A 3	FLYWHEEL ASSEMBLY (BELGIU	1		
2	28	20094	KEY, FLYWHEEL DRIVE	1		
3	12	36245	WASHER, FLYWHEEL NUT	1		
4	11	20696	NUT, FLYWHEEL	1		
5	339	5748A 2	COIL ASSEMBLY, IGNITION	2		
6	13	26996	LOCKWASHER, IGNITION COIL T	4		
7	11	45076	NUT, IGNITION COIL TERMINAL	4		
8		66355	COVER, IGNITION COIL	2		
9	10	72074	SCREW, COIL COVER TO REAR	3		
10	11	20110	NUT, COIL COVER SCREW	3		
11	84	63212A 2	LEAD ASSEMBLY, HIGH TENSIO	2		
12	332	2854	NIPPLE, IGNITION COIL	2		
13	85	71006A 1	PROTECTOR ASSEMBLY, SPARK	2		
14	33	58194	SPARK PLUG (AC#V40FFK)	2	BELGIUM AND CANADA USE C	