



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	53	26406	RING, SNAP - BALL BEARING RE	1,1,1		
2	30	26379	BEARING, BALL - DRIVE SHAFT	1,1,1		
3	45	30573	DRIVE SHAFT < DISTRIBUTOR	1,1,1		
4		39559A	PILOT ASSEMBLY, DISTRIBUTOR	1,1	SERIAL 00000000-02101742	
4		45483A	PILOT ASSEMBLY, DISTRIBUTOR	,1	SERIAL 00210743-09999999	
5	12	45484	WASHER, DISTRIBUTOR TO PI	,1,1		
4		45960A	PILOT ASSEMBLY, DISTRIBUTOR	,,1		
6	30	20066	BEARING, BALL - DISTRIBUTOR	1,1,1		
7	24	29275	SPRING, HORSESHOE	1,1,1		
8	17	27962	PIN, SPRING TERMINAL	1,1,1		
9		32197	STOP, SPRING TERMINAL	1,1,1		
10		30580A	ECONOMIZER COLLAR AND PIN	1,1,1		
11	17	27961	PIN, SPRING RETAINER	1,1,1		
12	22	25094	FITTING, GREASE - ECONOMIZ	1,1,1		
13		32044A	THROTTLE ACTUATOR ASSEMB	1,1,1		
14	23	26602	BUSHING, NYLON - THROTTLE	1,1,1		
15	10	20100	SCREW, THROTTLE ACTUATOR	2,2,2		
16	13	26996	LOCKWASHER, THROTTLE ACTI	2,2,2		
17	12	20128	WASHER, THROTTLE ACTUCATI	2,2,2		
18		30645	ADAPTOR, DISTRIBUTOR	1,1,1		
19	22	25094	FITTING, GREASE - ADAPTOR	1,1,1		
20		30585	BRACKET, STOP	1,1,1		
21	10	28636	SCREW, STOP BRACKET TO DIS	2,2,2		
22	12	20533	WASHER, STOP BRACKET FAST	2,2,2		
23		37747	GROUND STRAP, STOP BRACK	1,,		
24	10	24228	SCREW, STOP BRACKET ADJUS	3,3,3		
25	11	20890	NUT, STOP BRACKET ADJUSTIN	3,3,3		
26		26852	CAP, NYLON - ADJUSTING SCRE	3,3,3		
27	10	22040	SCREW, ADAPTOR AND PILOT T	3,3,3		
28	12	20084	WASHER, ADAPTOR AND PILOT	3,3,3		
29	11	20083	NUT, ADAPTOR AND PILOT FAS	3,3,3		
30	12	27939	WASHER, THRUST - DISTRIBUT	1,1,1		
31	14	27960	TAB WASHER, CAP LOCKING	1,1,1		
32	13	27959	WASHER, WAVE - TAP WASHER	1,1,1		
33		27955	CAP, ADAPTOR AND PILOT FAST	1,1,1		
34	10	31299	SCREW, ADAPTOR AND PILOT T	4,4		
34	10	20532	SCREW, ADAPTOR AND PILOT T	,,4		
35	13	26992	LOCKWASHER, ADAPTOR AND F	,,4		
36	23	29909	SPACER, DRIVEN PULLEY	1,1,1		
37		29906A	DRIVEN PULLEY ASSEMBLY	1,1,1		
38	17	28908	PIN, DRIVE PULLEY	1,1,1		