



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	1440	1796A 1	CLAMP BRACKET ASSEMBLY	2,2,2		
2		28403A 3	THUMB SCREW ASSEMBLY	2,2,2		
3	12	28404	WASHER, THUMB SCREW	2,2,2		
4		30664	TUBE, TILT - CLAMP BRACKET T	1,1,1		
5	15	30497A 1	SHIM, CLAMP BRACKET TILT TU	2,2,2		
6	11	30499	NUT, TILT TUBE FASTENING	2,2,2		
7		30498	CAP, PLASTIC - TILT TUBE	2,2,2		
8	23	20222	SPACER, CLAMP BRACKET STUC	1,1,1		
9	16	20221	STUD, CLAMP BRACKET	1,1,1		
10	13	26993	LOCKWASHER, CLAMP BRACKE	2,2,2		
11	11	20083	NUT, CLAMP BRACKET STUD	2,2,2		
12	17	30687A 1	TILT LOKC PIN ASSEMBLY	1,1,1		
13	32	28052	SLEEVE, RUBBER - TILT PIN BU	1,1,1		
14	1453	2690A 1	SWIVEL BRACKET ASSEMBLY(SH	1,1,1		
14	1447	2689A 1	SWIVEL BRACKET ASSEMBLY(LC	1,1,1		
15	26	37448	OIL SEAL	2,2,2		
16	24	28659	SPRING, COIL - SWIVEL BRACK	1,1,1		
17	17	38311	PIN, COIL SPRING MOUNTING	1,1,1		
18	22	23612	FITTING, GREASE	1,1,1		
19		29359	LUBRICAP, SWIVEL BRACKET GF	1,1,1		
20		30126A 1	TILT STOP LEVER ASSEMBLY	1,1,1		
21	10	30128	SCREW, TILT STOP LEVER ANCH	2,2,2		
22	13	31030	WASHER, WAVE - LEVER ANCHC	2,2,2		
23	11	46793	NUT, LEVER ANCHOR SCREW	2,2,2		
24	17	37462A 1	SWIVEL PIN AND STEERING ARM	1,1,1		
24	17	37423A 1	SWIVEL PIN AND STEERING ARM	1,1,1		
25		28203	BUMPER, STEERING ARM	1,1,1		
26	10	31257	BOLT, STEERING ARM TO UPPE	2,2,2		
27	11	22178	NUT, STEERING ARM BOLT FAS	2,2,2		
28	10	31830	SCREW, RIDE-GUIDE ATTACHIN	1,1,1		
29	11	20509	NUT, RIDE-GUIDE ATTACHING S	1,1,1		
30	12	37429	WASHER, SWIVEL PIN - LOWER	1,1,1		
31		37419	YOKE, BOTTOM	1,1,1		
32	11	37424	NUT, SWIVEL PIN RETAINING	1,1,1		
33		28205	STRAP STOP, DRIVE SHAFT HO	1,1,1		
34	10	28200	SCREW, STRAP STOP TO DRIVE	1,1,1		
35	11	25269	NUT, STRAP STOP FASTENING	1,1,1		
36	23	28688	SPACER, RUBBER - COIL SPRINC	2,2,2		
37	55	28416	PIN, UPPER SHOCK MOUNTING	1,1,1		
38	10	28009	BOLT, CLAMP BRACKET TO BOA	2,2,2		
38	12	28008	WASHER, CLAMP BRACKET BOL	2,2,2		