



DO NOT touch this adjustment.
 This is preset by the manufacturer, and is NOT for field service. Conventional carb. cleaners will not affect the sealant securing this adjustment.

Quicksilver Lubrication/Sealant
 Application Points

- 7 Loctite 271 (Obtain Locally)
- 109 Loctite Primer 'T' (92-59327-1)

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
16	10	F10155	SCREW-THROTTLE VALVE	8		
17	1395	811220	SCREW-COVER PLATE	8		
18	1395	808612	SCREW-FUEL BOWL	16		
19	1395	811221	COVER PLATE	4		
20	1395	6359	MAIN FUEL JET (.048)	1	(WME-50-1)	
20	1395	6028	MAIN FUEL JET (.050)	2	(WME-50-2/3)	
20	1395	6359	MAIN FUEL JET (.052)	1	(WME-50-4)	
20	1399	4217	MAIN FUEL JET (.062)	3	(WME-51-1/2/3)	
20	1399	4216	MAIN FUEL JET (.064)	1	(WME-51-4)	
20	1395	6030	MAIN FUEL JET (.070)	1	(WME-52-1)	
20	1395	6201	MAIN FUEL JET (.080)	2	(WME-52-2/3)	
20	1399	3518	MAIN FUEL JET (.082)	1	(WME-52-4)	
20	1395	6359	MAIN FUEL JET (.048)	1	(WME-79-1)	
20	1395	6028	MAIN FUEL JET (.050)	2	(WME-79-2/3)	
20	1395	6359	MAIN FUEL JET (.052)	1	(WME-79-4)	
20	1395	6487	MAIN FUEL JET (.060)	1	(WME-80-1)	
20	1399	4216	MAIN FUEL JET (.064)	1	(WME-80-2/4)	
20	1399	4217	MAIN FUEL JET (.062)	3	(WME-80-3)	
20	1395	6030	MAIN FUEL JET (.070)	1	(WME-81-1)	
20	1395	6201	MAIN FUEL JET (.080)	2	(WME-81-2/3)	
20	1399	3518	MAIN FUEL JET (.082)	1	(WME-81-4/52-4)	
21	1395	808738	GASKET-NOZZLE WELL	4		10,11
22			SPRING-IDLE NEEDLE	2		10
23			SPRING-THROTTLE RETURN	4		10
24			IDLE NEEDLE	2		10
25	1395	823634	SCREW	3		
.	1395	811223	CARB GASKET SET	1		10
.	1395	823635	CARB REPAIR KIT	1		