



15181

Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1		44331 4	IGNITION PLATE	1		
2	332	5772A 5	SWITCH BOX ASSEMBLY	1		
3	54	63153	J CLIP	1		
4	10	40011110	SCREW, (M5 x 30)	4		
5		13473 1	FUSE HOLDER, Old Design	1		
6	11	45076	NUT, (#10-32)	13		
7	84	43442A 3	PRIMARY HARNESS ASSMENBL'	1		
8	84	813715A 8	HIGH TENSION CABLE	1		
9	85	63709A 1	BOOT KIT	4		
10	33	97180	SPARK PLUG	4	(NGK #BUHW)	
10	33	14103550	SPARK PLUG	4	(Canda/Belguim NGK #BUZHW)	
10	33	816737 2	SPARK PLUG	4	(NGK #BP8H-N-10) RFI Suppressi	
10	33	816837 2	SPARK PLUG	4	(Canda/Belguim NGK #BPF28H-N-	
11	10	821550 25	SCREW, (M8 x 25)	4		
12	339	7370A13	IGNITION COIL ASSEMBLY	4		
13	11	45076	NUT, (#10-32)	8		
14		87554	COVER	1		
15	10	40007114	SCREW, (M5 X 50)	5		
16	12	89302	WASHER, (.203 x .406 x .040)	5		
18	10	40056107	SCREW, (M5 x 16)	2		
19	11	45067	NUT	3		
20		16731A 1	MERCURY SWITCH, Old Design	1		
21	10	40056107	SCREW, (M5 x 16)	1		
22		45915	TERMINAL BLOCK	2		
23	10	48408	SCREW, (#10-16 x .500)	4		
24	84	43443A 3	ENGINE WIRING HARNESS	1	SN# D252460 & Below	
24	84	43443A 7	ENGINE WIRING HARNESS	1	SN# D25461 & Up	
25	88	79091	FUSE, (20 Ampere)	1		
26	84	88439A 3	BATTERY CABLE, Positive	1		
26	84	88439A 4	BATTERY CABLE, Negative	1		
27	89	818998A 1	STARTER SOLENOID, (8-32 .250	1		
28	11	26419	NUT, (#8-32)	2		
29	13	26992	LOCKWASHER, (.250)	2		
30	11	64015	NUT, (#8-32)	2		
27	89	817109A 2	SOLENOID ASSEMBLY, (10-32 .31	1		
-	23	818968	BUSHING	2		
28	11	45076	NUT, (#10-32)	2		
29	13	53166	LOCKWASHER, (#10-32)	2		
30	11	68292	NUT, (#10-32)	2		
31	10	40007106	SCREW, (M5 X 13)	2		
32	12	4002214	WASHER	2		