



Parts List					
Ref	Class	Part	Description	Qty	Footnote
1	436	9072A 1	CRANKSHAFT ASSEMBLY	1	
2	30	62567	BALL BEARING, UPPER	1	
3	30	63742	BALL BEARING, LOWER	1	
4		54196A 6	CARRIER ASSEMBLY, "O" RING	1	
5		65800	"O" RING, CARRIER	1	13
6	535	5397A 4	CENTER MAIN BEARING ASSEMBLY	2	
7	17	20032	DOWEL PIN, CENTER MAIN BEARING	4	
8	29	71422	NEEDLE BEARING, OUTER RACE	112	
9		26113	RACE, OUTER (PAIR)	2	
10	53	26933	SNAP RING, OUTER RACE	2	
11	17	47246	DOWEL PIN, STEPPED	2	
12	10	22968	SCREW, CENTER MAIN BEARING	4	
13	11	20184	NUT, BEARING SCREW	4	
14	540	5266A 5	MAIN BEARING ASSEMBLY-90	3	
15	17	20032	DOWEL PIN, MAIN BEARING -90	6	
16	10	45775	SCREW, MAIN BEARING -90	6	
17	11	45774	NUT, MAIN BEARING SCREW -90	6	
18	34	56007A 1	REED SET, MATCHED -90	3	
19	34	56008	REED STOP, REED VALVES -90	12	
20	10	62204	SCREW, REED STOP -90	30	
21	11	53153	NUT, REED STOP SCREW -90	30	
14	540	8663A 3	MAIN BEARING ASSEMBLY-115	3	
15	17	20032	DOWEL PIN, MAIN BEARING -115	6	
16	10	45775	SCREW, MAIN BEARING -115	6	
17	11	45774	NUT, MAIN BEARING SCREW -115	6	
18	34	99422A 1	REED SET, MATCHED -115	3	
19	34	65319	REED STOP, 5 PETAL -115	6	
19	34	99421	REED STOP, 4 PETAL -115	6	
20	10	62204	SCREW, REED STOP -115	30	
21	11	53153	NUT, REED STOP SCREW -115	30	
22	776	8899A 3	PISTON/PISTON PIN ASSEMBLY	6	
22	776	8900A 2	PISTON/PISTON PIN ASSEMBLY	AR	12
22	776	8901A 2	PISTON/PISTON PIN ASSEMBLY	AR	12
22	774	8600A 3	PISTON/PISTON PIN ASSEMBLY	6	
22	774	9095A 1	PISTON/PISTON PIN ASSEMBLY	AR	12
22	774	9096A 1	PISTON/PISTON PIN ASSEMBLY	AR	12
23	40	52035	LOCK RING, PISTON PIN	12	
24	39	78816A12	PISTON RING (STANDARD)	2	
24	39	78811A12	PISTON RING (.015 OVERSIZE)	AR	12
24	39	88392A12	PISTON RING (.030 OVERSIZE)	AR	12
25	624	8101A 2	CONNECTING ROD AND CAPSCREW	6	