

| Parts List | | | | | | |
|------------|-------|----------|------------------------------|-----|----------------------------|----------|
| Ref | Class | Part | Description | Qty | Comment | Footnote |
| 1 | 1573 | 5239A 4 | DRIVE SHAFT HOUSING ASSEM | 1 | | |
| 2 | 16 | 56295 | STUD, DRIVE SHAFT HOUSING | 2 | | |
| 2 | 16 | 77168 | STUD, DRIVE SHAFT HOUSING | 2 | | |
| 3 | 19 | 64649 | PLUG, PLASTIC - TRIM TAB SCI | 1 | | |
| 5 | | 37417 | COVER, TRIM - DRIVE SHAFT HC | 1 | | |
| 6 | 10 | 57807 | SCREW, TRIM COVER TO BOTTC | 4 | | |
| 6A | 25 | 57806 | GROMMET, PLASTIC - TRIM COV | 4 | | |
| 6B | | 46933A 2 | GROUND STARP ASSEMBLY, TR | 2 | | |
| 6C | 10 | 62568 | SCREW, GROUND STRAP ATTAI | 2 | | |
| 7 | 32 | 60897 | TUBE, WATER INLET (LONG SHA | 1 | | |
| 7 | 32 | 77121 | TUBE, WATER INLET (EXTRA LO | 1 | | |
| 8 | | 78184 | TUBE, EXHAUST | 1 | | |
| 8A | | 65638 | BOOT, TUBE MOUNT | 2 | | |
| 11 | 11 | 69254 | NUT, POWERHEAD STUDS (3/8- | 2 | | |
| 12 | 12 | 25970 | WASHER, POWERHEAD STUDS | 2 | | |
| 14 | | 52887 | GUIDE, PUSH ROD - REVERSE L | 1 | - NOT USED WITH FULL POWER | |
| 15 | | 47558 | ROD, PUSH - REVERSE LOCK | 1 | - NOT USED WITH FULL POWER | |
| 16 | 11 | 47661 | NUT, JAM - PUSH ROD | 1 | - NOT USED WITH FULL POWER | |
| 17 | | 47559 | YOKE, PUSH ROD | 1 | - NOT USED WITH FULL POWER | |
| 19 | 18 | 25191 | COTTER PIN, PUSH ROD PIN | 1 | - NOT USED WITH FULL POWER | |
| 20 | | 75296 | MOUNT, RUBBER - UPPER | 2 | | |
| 21 | 12 | 47840 | WASHER, RUBBER - UPPER MOI | 2 | | |
| 22 | 12 | 31263 | WASHER, UPPER MOUNT BOLT | 2 | | |
| 23 | 11 | 34933 | NUT, UPPER MOUNT BOLT | 2 | | |
| 24 | | 75299 | MOUNT, RUBBER - LOWER | 2 | | |
| 25 | 10 | 49318 | SCREW, LOWER MOUNT (5 1/2" | 2 | | |
| 26 | 12 | 49339 | WASHER, LOWER MOUNT SCRE | 2 | | |
| 27 | 11 | 25096 | NUT, LOWER MOUNT SCREW | 2 | | |
| 28 | | 25067 | BUMPER, RUBBER - LOWER MO | 2 | | |
| 30 | 11 | 34933 | NUT | 2 | GEAR HOUSING AND DRIVE SH | |
| 31 | 12 | 45176 | WASHER | 2 | GEAR HOUSING TO DRIVE SHAF | |
| 32 | 11 | 29489 | NUT, GEAR HOUSING AND DRIV | 1 | | |
| 33 | 12 | 45176 | WASHER | 1 | GEAR HOUSING TO DRIVE SHA | |
| 34 | | 35608 | CLAMP, LOWER MOUNT TO DRI | 2 | | |
| 35 | 24 | 35522 | SPRING, TENSION - LOWER MOI | 4 | | |
| 36 | 10 | 29256 | SCREW | 4 | LOWER MOUNT CLAMP TO DRI | |
| 37 | | 35474 | COVER, LOWER MOUNT CLAMP | 2 | | |
| 38 | 11 | 35521 | NUT, LOWER MOUNT CLAMP CC | 2 | | |
| 39 | 10 | 29722 | SCREW, COVER TO LOWER CLA | 2 | | |
| -- | | 77120 | SPACER | 1 | DRIVE SHAFT HOUSING - EXTR | |
| 17 | | 21428 | DOWN PIN SPACER - EXTRA L | 2 | | |

