



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	2114	7934	TOP COWL (BLACK)	1		1
2		93122A	1 RETAINER ASSEMBLY, TOP COV	1		
3	10	53167	SCREW, RETAINER TO TOP COV	1		
4	13	39107	LOCKWASHER, RETAINER SCRE	1		
5		76370	SHIELD, TOP COWL - REAR (BLA	1		
6	10	48409	SCREW, SHIELD TO TOP COWL	3		
1	2162	6392T	6 TOP COWL (GRAY)	1		1
2		76440	RETAINER ASSEMBLY, TOP COV	1		
3	10	25299	SCREW, RETAINER TO TOP COV	1		
4	13	39107	LOCKWASHER, RETAINER SCRE	1		
5		76433	SHIELD, TOP COWL - REAR (GRZ	1		
6	10	48409	SCREW, SHIELD TO TOP COWL	3		
7		47341A	1 ROPE, STARTER (FOR MANUAL	1		
8		52739T	HINGE, COWL LATCH - TOP COW	1		
9		94918T	LEVER, COWL LATCH HINGE	1		
10	17	58998	ROLL PIN, COWL LATCH LEVER	1		
11		55455	HOOK, TOP COWL LATCH - REAF	1		
12	10	22956	SCREW, REAR HOOK TO TOP CC	2		
13	13	26992	LOCKWASHER, REAR HOOK SCF	2		
14		79897A	4 FRAME, TOP COWL SUPPORT	1		
15		90435	MOUNT, RUBBER - TOP COWL F	3		
15		46096	MOUNT, RUBBER - TOP COWL F	OPT		
16	11	20184	NUT, RUBBER MOUNT	6		
17		86472	BRACKET, TOP COWL SUPPORT	1		
18		31014	MOUNT, RUBBER - REAR SUPPC	2		
19	13	26992	LOCKWASHER, RUBBER MOUNT	2		
20	11	29598	NUT, RUBBER MOUNT	2		
21	10	37562	SCREW, REAR BRACKET TO FR	4		
22	13	26993	LOCKWASHER, REAR BRACKET	4		
23	10	37562	SCREW, REAR BRACKET TO BO	4		
24	13	26993	LOCKWASHER, REAR SUPPORT	4		
25		42706A	1 BRACKET ASSEMBLY, TOP COW	1		
26	10	69092	SCREW	2	FRONT BRACKET TO BOTTOM	
27	13	26993	LOCKWASHER, FRONT SUPPOR	2		
28	10	69092	SCREW	2	FRONT BRACKET TO TOP COW	
29	13	26993	LOCKWASHER, FRONT SUPPOR	2		
30		37640	MOUNT, RUBBER - FRONT SUPP	1		
31	13	26993	LOCKWASHER, RUBBER MOUNT	1		
32	11	28770	NUT, RUBBER MOUNT	1		
33		87991	1 POINTER, TIMING	1		
34	10	28626	SCREW, TIMING POINTER (3/4")	1		