



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		43289A	2 PLATE ASSEMBLY, EXHAUST EX	1		
2	23	27132	BUSHING, NYLON - EXHAUST E	1		
3	17	23784	DOWEL PIN, EXHAUST EXTEN	2		
4		37918	SEAL, EXHAUST PLATE	1		
5		99358	STRIP, RETAINING - EXHAUST	1		
6	10	37571	SCREW	5	SEAL AND RETAINING STRIP TI	
7	27	69238	1 GASKET, POWERHEAD	1		13,2
8	10	66023	SCREW, ADAPTOR PLATE TO H	2		
9	10	66023	SCREW	7	HOUSING PLATE TO DRIVE SH	
10	27	66102	GASKET, DRIVE SHAFT HOUSINI	1		13,2
11	26	60898	SEAL, DRIVE SHAFT HOUSING P	1		
12		43290A	4 PLATE ASSEMBLY, DRIVE SHAF	1		
13	26	38970	SEAL, RUBBER - WATER INLET	1		13,2
14	17	23784	DOWEL PIN, DRIVE SHAFT HOU:	2		
15		99699	EXHAUST MEGAPHONE (90)	1		
16	10	99700	EXHAUST TUBE (115)	1		
16	10	65414	SCREW	4	EXHAUST TUBE TO DRIVE SHA	