



Parts List					
Ref	Class	Part	Description	Qty	Footnote
1		13527A 1	FUEL PUMP ASSEMBLY	1	
2	21	30430A14	CHECK VALVE ASSEMBLY	1	
3		89031A 3	DIAPHRAGM ASSEMBLY	1	13
4			GASKET, FUEL PUMP	1	13
5			GASKET, PULSE CHAMBER	1	13
6			GASKET, FUEL PUMP	2	13
7			GASKET, CHECK VALVE TO	2	13
8	35	59072	SCREEN, FUEL INLET	1	13
9	25	35480	"O" RING, FUEL INLET COV	1	13
10	25	38933	GASKET, COVER SCREW	1	13
11		23004	RETAINER, CHECK VALVE	1	
12	10	43723	SCREW, RETAINER	2	
13		86295	BASE, FUEL PUMP	1	
14		87990 1	PULSE CHAMBER, FUEL PUMP	1	
15	35	91078A 1	COVER, FUEL INLET	1	
16	10	89766	SCREW, FUEL FILTER COVER	1	
17	22	64705	FITTING, INLET COVER	1	
18	10	F1979	SCREW, FUEL PUMP (1-1/2")	5	
19	13	26996	LOCKWASHER, FUEL PUMP SC	5	
20	22	19688	FITTING, FUEL OUTLET	1	
21		86026	RETAINER, SPRING	1	
22	24	86207	SPRING, COMPRESSION	1	
23		86252	CAP, SPRING END	1	
24	32	99127109	FUEL LINE, FUEL PUMP (w/O INI	4	
25	54	68424	CLAMP, FUEL LINE ATTACHING	10	
26	22	19688	FITTING, ELBOW - UPPER CARBI	1	
27	22	73318	TEE, FUEL LINE	1	
28	22	64706	FITTING, TEE - CENTER CARBUF	1	
29	22	19688	FITTING, ELBOW - LOWER CARB	1	
30	32	99127109	FUEL LINE, ADAPTOR TO FUEL F	1	
31	22	63981	ELBOW, FUEL LINE TO ADAPTOR	1	
32		30186	ADAPTOR, CHECK UNIT	1	
33		30187	STEM, CHECK UNIT ADAPTOR	1	
34	24	30189	SPRING, ADAPTOR STEM	1	
35	25	20415	"O" RING, ADAPTOR STEM	1	13
36		30188	CUP WASHER, ADAPTOR	1	
37	10	36154	SCREW, ADAPTOR TO BOTTON	2	
38	11	36069	NUT, ADAPTOR SCREW	2	
39	32	99127109	FUEL LINE -WITH INLINE FILTER	1	
40	54	68424	CLAMP, FUEL LINE -WITH INLINE	2	
41	25	16484	FUEL FILTER -WITH INLINE FILT	1	