



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
-	1655	7333A24	GEAR HOUSING (LONG) (BLACK)	1		
-	1655	7333A26	GEAR HOUSING (X-LONG) (BLACK)	1		
-	1655	7333A42	GEAR HOUSING (LONG) (GRAY)	1		
-	1655	7333A44	GEAR HOUSING (X-LONG) (GRAY)	1		
1	1655	7333A23	GEAR HOUSING ASSEMBLY (BI)	1		
1	1655	7333A43	GEAR HOUSING ASSEMBLY (G)	1		
2	22	85822A	CONNECTOR ASSEMBLY, SP	1		
3	17	85500	DOWEL PIN, GEAR HOUSING	2		
4	16	57921	STUD, GEAR HOUSING (4") (L)	1		
4	16	77169	STUD, GEAR HOUSING, (9") (L)	1		
5	16	57920	STUD, GEAR HOUSING (2-1/4")	2		
5	16	74730	STUD, GEAR HOUSING (7") (E)	2		
6	16	56297	STUD, WATER PUMP (3-3/8")	1		
7	16	69501	STUD, WATER PUMP (3-1/8")	2		
8	31	32898	ROLLER BEARING, DRIVE SH	1		
9	45	42646	DRIVE SHAFT (LONG SHAFT)	1		
9	45	42645	DRIVE SHAFT (EXTRA LONG SI)	1		
10	43	68548	PINION GEAR	3		
11	11	35921	NUT	1		
12	23	70412	SPACER	1		
13	15	57007A	SHIM	AR		12
14	31	69220	ROLLER BEARING	1		
15	27	85610	GASKET	1		13,2,8,11
16	25	33145	"O" RING	1		13,2,8,11
17	46	96146A	WATER PUMP ASSEMBLY	5		8
18	26	94038	OIL SEAL, WATER PUMP	1		8,11
19	26	16977	OIL SEAL, WATER PUMP	1		8,11
20	27	85608	GASKET, LOWER - WATER PUI	1		13,2,8,11
21		32435	FACE PLATE	1		8
22	27	85609	GASKET, UPPER - FACE PLATE	1		13,2,8,11
23	46	96148A	WATER PUMP BODY ASSEMBL	1		8
24		48752	INSERT, WATER PUMP	1		8
25	26	38970	SEAL, RUBBER - WATER INLI	1		8,11
26	47	89984	IMPELLER, WATER PUMP	1		8
27	28	56654	KEY, IMPELLER DRIVE	1		8
28	10	96411	SCREW, WATER PUMP	1		8
29	12	20583	WASHER, WATER PUMP SCRE	1		
30	12	29245	WASHER, WATER PUMP SCRE	2		
31	11	13438	NUT, WATER PUMP SCREW	2		
32	12	36001	WASHER, WATER PUMP STUC	1		
33	11	26914	NUT, WATER PUMP STUD	1		