



Parts List					
Ref	Class	Part	Description	Qty	Footnote
1		66530A 6	FUEL PUMP ASSEMBLY	1	
2	21	30430A10	CHECK VALVE ASSEMBLY	1	
3		66599A 3	DIAPHRAGM ASSEMBLY	1	6
4			GASKET FUEL PUMP	1	6
5			GASKET, PULSE CHAMBER	1	6
6			GASKET, FULE PUMP	2	6
7			GASKET, CHECK VALVE TO	2	6
8	35	59072	SCREEN, FUEL INLET	1	6
9			"O" RING, FUEL INLET COV	1	6
10			GASKET, COVER ATTACHIN	1	6
11		23004	RETAINER, CHECK VALVE	1	
12	10	20037	SCREW, RETAINER ATTACHING	2	
13		86295	BASE FUEL PUMP	1	
14		87990	CHAMBER, PULSE - FUEL PUM	1	
15		59071	COVER, FULE INLET	1	
16	10	37370	SCREW, FUEL FILTER COVER	1	
17	10	73013	SCREW, FUEL PUMP ATTACHII	5	
18	13	26996	LOCKWASHER, FUEL PUMP AT	5	
19	22	64704	FITTING, FUEL OUTLET	1	
20	32	70432	FUEL LINE	4	FUEL PUMP TO CARBURETOR I
21	54	68424	CLAMP, FUEL LINE ATTACHING	10	
22	22	64704	FITTING, ELBOW - UPPER CARBI	1	
23	22	73318	TEE, FUEL LINE	1	
24	22	64706	FITTING, TEE - CENTER CARBUF	1	
25	22	64704	FITTING, ELBOW - LOWER CARB	1	
26	32	70432	FUEL LINE, ADAPTOR TO FUEL F	1	
27	22	63981	ELBOW, FULE LINE TO ADAPTOF	1	
28		22833	ADAPTOR, CHECK UNIT (FUEL LI	1	
29		23069	STEM, CHECK UNIT ADAPTOR	1	
30	24	23067	SPRING, ADAPTOR STEM	1	
31	25	20415	"O" RING, ADAPTOR STEM	1	6
32		30188	CUP WASHER, ADAPTOR	1	
33	10	69029	SCREW, ADAPTOR TO BOTTOM	2	
34	11	36069	NUT, ADAPTOR SCREW	2	