



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
-		76395A 5	HYDRAULIC PUMP ASSEMBLY, C	1		
1	25	48171	"O"RING, HYDRAULIC PUMP	4		
2	392	2936	VALVE BODY AND GEAR ASSE	1		
3	10	20411	SCREW, VALVE BODY TO RESI	8		
4	392	2937	SEAL, RESERVOIR TO VALVE E	1		
5	392	2939	RESERVOIR ASSEMBLY	1		
6	10	38257	SCREW, VENT - HYDRAULIC PI	1		
7	10	79953	SCREW, FILLER - HYDRAULIC I	1		
8	12	20260	WASHER, SEALING - FILLER SI	1		
9	392	2623	WASHER, THRUST - ARMATUF	AR		3
10	392	2943	ARMATURE, FIELD AND FRAMI	1		
11	392	2942	FIELD AND FRAME ASSEMBLY	1		
12	392	2944	BALL, COMMUTATOR END PLA	1		
13	392	2940	PLATE ASSEMBLY, COMMUTA	1		
14	392	2941	BRUSH SET, COMMUTATOR	1		
15	392	2529	SPRING SET, BRUSH TENSION	1		
16	392	2938	BOLT SET	1	THRU - PLATE AND FRAME TO	
17	13	26996	LOCKWASHER, THRU BOLT	2		