



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	339	7370A 2	IGNITION COIL	6		
2		73218	COVER, IGNITION COIL	2		
3		88856	SCREW, IGNITION COIL COVER	12		
4	11	45076	NUT, IGNITION COIL TERMINAL	12		
5	84	60466A 1	CABLE ASSEMBLY, IGNITION CO	6		
6	84	90816A25	CABLE, HIGH TENSION	6		
7	332	2854	BOOT, COIL END	6		
8	85	63709A 1	PROTECTOR, SPARK PLUG EN	6		
9	33	68057	SPARK PLUG (CHAMPION #L76-V	6		
10	84	85537A 2	HARNESS, COIL TO SWITCH BO	1		
10	84	85537A 1	HARNESS, COIL TO SWITCH BO	1		
11	54	63153	CLIP, HARNESS TO COIL COVER	2		
12	84	89564A 1	WIRING HARNESS	1	UNITED STATES 6051525 AND	
12	84	96188A 2	WIRING HARNESS	1	UNITED STATES 6051526 AND I	
13	88	79091	FUSE	1	UNITED STATES 6051526 AND I	
14	84	95084A 2	WIRE, FUSE HOLDER	1	UNITED STATES 6051526 AND I	
15	54	88608	CLAMP, WIRING HARNESS	1		
16	10	28636	SCREW, WIRING HARNESS CLAI	2		
17	13	26996	LOCKWASHER, WIRING HARNE	2		
18		89047	BRACKET, WIRING HARNESS	1		
19	10	24637	SCREW, WIRING HARNESS BRA	2		
20	12	38833	WASHER, BRACKET SCREW	2		
21	11	20110	NUT, BRACKET SCREW	2		
22		88751	CLAMP, WIRING HARNESS	1		
23	10	28636	SCREW, WIRING HARNESS CLAI	1		
24	12	20533	WASHER, CLAMP SCREW	1		
25	84	88439A 3	BATTERY CABLE (POSITIVE)	1		
25	84	88439A 4	BATTERY CABLE (NEGATIVE)	1		