



Parts List					
Ref	Class	Part	Description	Qty	Footnote
-	1655	7333A24	GEAR HOUSING ASSY. COMPLE	1	
-	1655	7333A26	GEAR HOUSING ASSY. COMPLE	1	(EXTRA LONG SHAFT)
1	1655	7333A23	GEAR HOUSING ASSEMBLY	1	
1A	22	85822A 1	CONNECTOR ASSEMBLY. SP	1	
2	17	46912	DOWEL PIN. GEAR HOUSING	2	
3	16	57921	STUD. GEAR HOUSING (4") (L	1	
3	16	77169	STUD. GEAR HOUSING (9") (E	1	
4	16	57920	STUD. GEAR HOUSING (2-1/8"	2	
4	16	77173	STUD. GEAR HOUSING (7") (E	2	
5	16	56297	STUD. WATER PUMP (3-3/8"	1	
6	16	69501	STUD. WATER PUMP (3-1/8"	2	
7	31	32898	ROLLER BEARING, DRIVE SH-	1	
8	45	76036	DRIVE SHAFT (LONG SHAFT)	1	
8	45	77159	DRIVE SHAFT (EXTRA LONG SI	1	
9	43	68548	PINION GEAR, DRIVE SHAFT	1	
10	11	35921	NUT, PINION GEAR TO DRIVE	1	
11	23	70412	SPACER, BALL BEARING	1	
11	15	57007A 1	SHIM, BALL BEARING	AR	3
12	31	69220	ROLLER BEARING, DRIVE SHA	1	
14	27	33146	GASKET, WATER PUMP	1	2
15	25	33145	"O" RING, WATER PUMP	1	2
16	46	96146A 5	WATER PUMP BASE ASSEMBL	1	
17	26	94038	OIL SEAL, WATER PUMP	1	
18	26	79884	OIL SEAL, WATER PUMP	1	
19	17	35973	DOWEL PIN, WATER PUMP	AR	3
20	27	32433	GASKET, LOWER-WATER PUM	1	2
21		32435	FACE PLATE	1	
22	27	32434	GASKET, UPPER-FACE PLATE	1	2
23	46	96148A 1	WATER PUMP BODY ASSEMBL	1	
24		48752	INSERT, WATER PUMP	1	
26	26	38970	SEAL, RUBBER-WATER INLE	1	
27	47	89984	IMPELLER, WATER PUMP	1	
28	28	56654	KEY, IMPELLER DRIVE	1	
29	10	30720	SCREW, WATER PUMP (1/4-20	AR	3
29	10	96411	SCREW, WATER PUMP (1/4-8-H	AR	3
30	13	26992	LOCKWASHER, WATER PUMP	1	
31	12	29245	WASHER, WATER PUMP SCRE	3	
32	11	35888	NUT, WATER PUMP SCREW	2	
33	12	36001	WASHER, WATER PUMP STUC	1	
34	11	35814	NUT, WATER PUMP STUD	1	
35	25	20271	RING, RUBBER DRIVE SHAFT	1	2