



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
-	1655	7333A24	GEAR HOUSING ASSY, COMPLE	1		
-	1655	7333A26	GEAR HOUSING ASSY, COMPLE	1	(EXTRA LONG SHAFT)	
1	1655	7333A23	GEAR HOUSING ASSEMBLY	1		
49		76039	SHIFT CAM	1		
50		30625	CAM FLOWER	1		
51		30624	SLIDE, CROSS PIN	1		
52	24	30622	SPRING, COMPRESSION - CAM	1		
53	15	30923A 1	SHIM, BEARING OUTER RACE	AR		3
54	31	30894A 1	TAPERED ROLLER BEARING A	1		
55	31	30895	ROLLER BEARING, FORWARD	1		
56	43	68447A 1	FORWARD GEAR	1		
57	52	34239	RATCHET, SLIDING GEAR	1		
58	17	30632	CROSS PIN, RATCHET TO PRO	1		
59	24	30893	SPRING, RETAINING - CROSS F	1		
60	44	93003	PROPELLER SHAFT	1		
61	43	76250	REVERSE GEAR	1		
62	12	76805	WASHER, THRUST - BEARING	1		
63	25	29976	"O"RING, BEARING CARRIER	1		2
64		96074A 1	BEARING CARRIER ASSEMBLY	1	W/O GREASE FITTING	
64		41529A 1	BEARING CARRIER ASSEMBLY	1	W/GREASE FITTING	
64A	22	98727	GREASE FITTING	2		
65	31	30956	ROLLER BEARING	1	BEARING CARRIER-W/GREASE	
66	26	76868	OIL SEAL (INSIDE)	1		
66	26	70081	OIL SEAL, CUTTER (OUTSIDE)	1		
67	28	30281	KEY, LOCATING - BEARING CARR	1		
68	14	52700	TAB WASHER, GEAR HOUSING	1		
69		52699	COVER, GEAR HOUSING	1		
70		31640A 1	TRIM TAB, GEAR HOUSING	1		
71	10	66024	SCREW, TRIM TAB TO GEAR H	1		
72	12	45176	WASHER, DRIVE SHAFT HOUSIN	2		
73	11	34933	NUT, DRIVE SHAFT HOUSING S	2		
74	10	65210	SCREW, GEAR HOUSING (LONG	1		
74	10	77167	SCREW, GEAR HOUSING (EXTR	1		
75		75282	THRUST HUB AND WASHER AS	1		
76	14	31210	TAB WASHER, PROPELLER NUT	1		
77	11	52707	PROPELLER NUT	1		
-	27	85653A32	GASKET SET			