



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	852	7740A 3	BLOCK/CRANKCASE ASS'	1	UNITED STATES 5829463 AND I	
1	852	7739A 3	BLOCK/CRANKCASE ASS'	1	UNITED STATES 5829464 THRL	
1	852	8310A 4	BLOCK/CRANKCASE ASSY	1	UNITED STATES 6051526 AND I	
2	27	53862	GASKET, CRANKCASE TO CYLI	2		2
3		66517	RESTRICTION, CRANKCASE BLE	5		
4	16	64280	STUD, CRABURETOR (1-3/16")	6		
5	16	64281	STUD, CRANKCASE TO EXTENS	2		
6	17	20033	DOWEL PIN, CRANKCASE TO C	2		
7	17	63779	DOWEL PIN, CYLINDE BLOCK	3		
8	16	64282	STUD, CYLINDER BLOCK TO PI	6		
9		86473	COVER, STARTER MOTOR-TOF	1		
10	10	69268	SCREW, TOP COVER (1-7/8")	2		
11	13	26993	LOCKWASHER, TOP COVER SC	2		
13		76867	COVER, STARTER MOTOR BR/	1		
14	10	69268	SCREW, BOTTOM COVER (1-7/	2		
15	13	26993	LOCKWASHER, BOTTOM COVE	2		
17	10	57841	SCREW, CRANKCASE TO CYLIN	3		
17	10	32293	SCREW, CRANKCASE TO CYLIN	3		
17	10	73657	SCREW, CRANKCASE TO CYLIN	20		
17	10	53016	SCREW, CRANKCASE TO CYLIN	2		
18	12	22753	WASHER, CRANKCASE SCREWS	25		
19	11	29250	NUT, CRANKCASE SCREWS (LO	2		
20	10	20359	SCREW, CENTER MAIN BEARIN	2		
21	14	20091	TAB WASHER, BEARING LOCKI	2		
25	21	77560	CHECK VALVE, BLEED HOSE-UP	1		
26	32	54935 79	HOSE, BLEED (22")	1		
27	21	77561	CHECK VALVE, BLEED HOSE-LO	1		
28	22	25885	ELBOW, BALANCE HOSE	2		
29	32	34395A 1	HOSE, BALANCE-MAIN BEARING	2		
30	22	85578	TEE, BALANCE HOSE	1	UNITED STATES 6051525 AND I	
30	22	97231	TEE, BLEED HOSE	1	UNITED STATES 6051526 AND I	