



1688

Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1	3408	881919T01	SWIVEL BRACKET	1		
2	26	87735	SEAL, OIL	1		
3	23	818764	BUSHING	2		
4	25	33504	O-RING	1		
5	23	816039	SPACER	1		
6	22	74036	FITTING, Grease	2		
7	23	821207	BUSHING	2		
8	10	64014	SCREW, (.250-28 x .500)	2		
9		99661A35	SWIVEL PIN/STEERING ARM	1		
10		92876A10	LINK ROD ASSEMBLY	1		
11	10	849838	SCREW, (.375-24 x 1.250)	1		
12	11	826709113	NUT, (.375-24)	2		
13	12	37828	WASHER, (.390 x .625 x .062)	2		
14		881974	BUMPER	2		
15		881914T01	BOTTOM YOKE	1		
16	53	67684	RING, Retaining	1		
17	12	816432	THRUST WASHER	1		
18		NSS	NOT SOLD SEPARATE, Decal-Sea	1		
19		NSS	NOT SOLD SEPARATE, Decal-Sea	1		
20		821400A 2	POWER TRIM SENDER KIT	1		
21	84	11149A58	CABLE	1		
22	10	852368	SCREW, (#10-24 x .750)	2		
23	13	26996	LOCKWASHER, (#10)	2		
24	12	89302	WASHER, (.203 x .406 x .040)	2		