



2067

Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
0	1600	888845T01	GEAR HOUSING ASSEMBLY, Con	1	(LONG)	
0	1600	888845T02	GEAR HOUSING ASSEMBLY, Con	1	(X-LONG)	
1	1600	888845T	GEAR HOUSING, Basic	1	(BASIC)	
2		822773 1	INSERT, Threaded	2		24
3		888807	CAM FOLLOWER ASSEMBLY	1		24
4		892250	SHIFT CAM	1	SN# 0T845781 & Below	24
4		75771	SHIFT CAM	1	SN# 0T845782 & Up	
5		888806	ROD, Clutch Actuator	1		24
6	17	78905	PIN, Cross	1		24
7	17	78906	PIN, Spring Locator	1		24
8	24	79910	SPRING	1		24
9	12	78910	WASHER	1		24
10	15	44491A 1	SHIM SET	1		25
11	31	30894A 1	BEARING SET, Cup And Cone	1		
12		NSS	NOT SOLD SEPARATE, Cup	1		
13	43	881260A 3	GEAR, Forward (29 Teeth) (29 TE	1		
14	31	30895T	BEARING, Needle	1		25
15	53	856823	RING, Retaining	1		
16	52	888805T	CLUTCH	1		24
17	44	888804	PROPELLER SHAFT	1		
18	24	30893	SPRING	1		24
19	43	889991T	GEAR, Reverse (29 Teeth) (29 TI	1		
20		12596T 2	CARRIER ASSEMBLY, Bearing	1		
21	25	97386	O-RING, (3.609 x .139)	1		15
22	31	30956T	BEARING, Needle	1		25
23	26	70080	SEAL, Oil (INNER)	1		15
24	26	70081	SEAL, Oil (OUTER)	1		15
25	31	12578T	ROLLER BEARING	1		25
26	12	12577	THRUST WASHER	1		25
27	31	12576	BEARING, Thrust	1		25
28	16	42917 2	STUD, (M8 x 48)	2		
29	12	855941	WASHER	2		
30	11	40137 8	NUT, (M8)	2		
31		NSS	NOT SOLD SEPARATE, Decal	1		
-	26	43035A 4	SEAL KIT, Gear Housing	1		25
-	31	803496T 2	SEAL AND BEARING KIT	1	(w/O FORWARD BRG.)	
-	52	888805A00	REPAIR KIT, Clutch And Cam Follo	1		