



16458

Parts List					
Ref	Class	Part	Description	Qty	Footnote
1		881315T04	VAPOR SEPARATOR ASSEMBLY	1	22
1		881316T 2	COVER	1	22
2	25	881318	O-RING	1	22
3		881329	NEEDLE VALVE KIT	1	22
4		881320	FLOAT	1	22
5	17	881321	PIN, Float	1	22
6		881319T	BODY	1	22
7		881327	PLATE	1	22
8	10	881326 1	SCREW, (M3 x 8)	1	22
9	10	881326	SCREW, (M4 x 16)	7	22
10	27	881325	GASKET	1	22
11	25	881322002	DAMPER	1	22
12		880889T01	FUEL PUMP	1	22
13	35	881323T	FILTER	1	22
14		881324	COVER	1	22
15	10	881326 2	DRAIN SCREW	1	22
16	27	881328	GASKET	1	22
17	19	888265	CAP PLUG	1	22
18	32	881330A 1	HOSE KIT	1	22
19	54	881331	CLIP	2	22
20	54	881559	CLIP	5	22
21	35	892758002	FILTER/HOSE, Fuel	1	22
22	32	881560	HOSE	2	22
23	22	881558 1	TEE	5	22
24	32	881554	HOSE	1	22
25	32	881554	HOSE	1	22
26	32	881554	HOSE	1	22
27	32	881554	HOSE	6	22
28	32	881555	HOSE	1	22
29	32	881557	HOSE	1	22
30	32	881556	HOSE	1	22
31	25	881322 1	DAMPER	3	22
32	23	881332	COLLAR	6	22
33	54	881537	CLAMP	1	22
-		881440T04	INTAKE ASSEMBLY	1	