



2291

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	1598	881913T01	DRIVESHAFT HOUSING ASSEMB	1		
1	1598	881913T02	DRIVESHAFT HOUSING ASSEMB	1	(Jet)	
2	16	90350 1	STUD, (M10 x 100)	1	(Long)	
2	16	90350 15	STUD, (M10 x 227)	1	(X-Long)	
3	16	90350 12	STUD, (M10 x 63)	4	(Long)	
3	16	90350 16	STUD, (M10 x 190)	4	(X-Long)	
4	12	856774	WASHER, (.406 x .750 x .105)	5		
5	11	40140	NUT, (M10)	5		
6	22	85822A 4	PICKUP ASSEMBLY, Speedometer	1		
7	22	43335	CONNECTOR, (90 Degree)	1		
8	22	85822	CONNECTOR, (Straight)	1		
9		881916	MOUNT	2		
10	10	42973	BOLT, (M12 x 154)	2		
11	12	30119	WASHER, (.875 Inch Outside Diam	2		
12	11	43528	NUT, (M12)	2		
13		88238A10	WIRE ASSEMBLY, Ground	2		
14	10	41508	SCREW, (.250-20 x .500)	1		
15		881917	CLAMP	2		
16	11	35521	NUT	4		
17	10	889833025	SCREW, (M8 x 25)	4		
18		882752	COVER	2		
19	10	88417	SCREW, (#12-24 x .620)	4		
20	12	28421	WASHER, (1.5 x 3.05 x 0.13) Stain	2		
21	12	881976	WASHER, Neoprene	2		
22		12092A 3	SPACER KIT	1	(X-Long)	
23	17	43044	PIN, Dowel (.375 x .625) (Withou	1	(X-Long)(Rear)	
23	17	43043	PIN, Dowel (.375 x .625) (With Hc	1	(X-Long)(Front)	
24		892214	PLATE WASHER	2		
25	19	889557	PLUG, Driveshaft Housing	2		